			D'TTACH	HITCH FIT LIST
MFG	SIZE	MODEL	PART NUMBER	NOTES
				IF YOU CURRENTLY HAVE A ZRATOR MOUNT INSTALLED ONTO YOUR MOWER
ZRATO	R	ALL	*DTH-ZRA	DTH-ZRA IS A ZRATOR ADAPTER HITCH USED TO CONVERT HD ZRATOR MOUNT INTO A
				SINGLE HITCH RECEIVER FOR SINGLE HITCH D'TTACH ATTACHMENTS AND NO
				ADDITIONAL HITCH MOUNT IS REQUIRED.
BRADLEY	36"	Stand On Compact	DTHSM-UNI	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
Bradley	48"	Stand On Compact	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Bradley	52"	Stand On Compact	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
OBCAT	36"	Quick Cat (Stand On)	*DTHBOB-36QC	EXACT FIT
Bobcat	48"	Quick Cat (Stand On)	DTHALL-HD	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
obcat	52"	Quick Cat (Stand On)	DTHALL-HD	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Bobcat	61"	Quick Cat (Stand On)	DTHALL-HD	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Bobcat	61"	Predator Pro	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Bobcat	72"	Predator Pro	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Bobcat	61"	Pro Cat 6000MX	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Bobcat	52"	Pro Cat 6000	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Bobcat	61"	Pro Cat 6000	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Bobcat	48"	Pro Cat 5000	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Bobcat	52"	Pro Cat 5000	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Bobcat	61"	Pro Cat 5000	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Bobcat	36"	Fast Cat Pro SE	N/A (Not confirmed)	
Bobcat	42"	Fast Cat Pro SE	N/A (Not confirmed)	
Bobcat	48"	XRZ Pro RS	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Bobcat	52"	XRZ Pro & XRZ	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Bobcat	61"	XRZ Pro & XRZ	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Bobcat	42"	CRZ	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Bobcat	48"	CRZ	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Bobcat	52"	CRZ	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Bobcat	61"	CRZ	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
BAD BOY	61"	Renegade & Diesel Renegade	EQUIPPED	
Bad Boy	72"	Renegade & Diesel Renegade	EQUIPPED	
Bad Boy	54"-72"	Rogue	EQUIPPED	
Bad Boy	54"-72"	Rebel	EQUIPPED	

Bit DOG52"DiabloDTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSBig Dog60"DiabloDTH.G-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSBig Dog72"DiabloDTH.G-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSBig Dog38"Trooper (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSBig Dog52"Trooper (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSBig Dog52"Trooper (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSBig Dog60"Trooper (Stand On)DTH.G-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSBig Dog60"Trooper (Stand On)DTH.G-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSBill Y GOATN/AX3000 Stand On BlowerDTHZBEXACT FITBill Y GoatN/AZ3000 Stand On BlowerDTHZBEXACT FITCUB Cadet60"Pro 2 546 (S00 Series)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro 2 550 (S00 Series)DTH.G-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro 2 720 (700 Series)DTH.G-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro 2 720 (700 Series)DTH.G-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60" <th>Bad Boy</th> <th>36"-54"</th> <th>Revolt (Stand On)</th> <th>NOT CONFIRMED</th> <th>PLEASE CALL WITH MEASUREMENT BETWEEN CASTOR WHEELS</th>	Bad Boy	36"-54"	Revolt (Stand On)	NOT CONFIRMED	PLEASE CALL WITH MEASUREMENT BETWEEN CASTOR WHEELS
Big Dog60°DiabloDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSBig Dog72°DiabloDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSBig Dog36°Trooper (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 30-636 INCHES BETWEEN CASTOR WHEELSBig Dog48°Trooper (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 36-636 INCHES BETWEEN CASTOR WHEELSBig Dog60°Trooper (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 36-636 INCHES BETWEEN CASTOR WHEELSBig Dog60°Trooper (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 36-61 INCHES BETWEEN CASTOR WHEELSBig Dog60°Trooper (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSBill YooatN/AX3000 Stand On BlowerDTHZBEXACT FITCUB CADET48°Pro 2 548 (500 Series)DTHMD-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60°Pro 2 554 (500 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60°Pro 2 7560 (500 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60°Pro 2 7560 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72°Pro 2 7520 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60°Pro 2 760 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN			, ,		
Big Dog72"DiabloDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSBig Dog36"Trooper (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSBig Dog64"Trooper (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSBig Dog64"Trooper (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSBig Dog64"Trooper (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSBig Dog64"Trooper (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSBilLY GOATN/AX3000 Stand On BlowerDTHXBEXACT FITBilly GoatV/AZ3000 Stand On BlowerDTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro 2 546 (500 Series)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro 2 560 (000 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro 2 760 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro 2 760 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro 2 760 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro 3 260 (900 Series)DTHLG-UNITELESCOPIC CR					
Big Dog36"Trooper (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 26-26 INCHES BETWEEN CASTOR WHEELSBig Dog48"Trooper (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSBig Dog60"Trooper (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSBill Y GoatN/AX3000 Stand On BlowerDTHXBEXACT FITBill Y GOATN/AZ3000 Stand On BlowerDTHXBEXACT FITCUB CADET48"Pro 2 554 (S00 Series)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro 2 554 (S00 Series)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro 2 556 (S00 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro 2 760 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro 2 760 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro 2 772 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet74"Pro 2 760 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet74"Pro 2 760 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet74"Pro 2 760 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCH					
Big Dog48"Trooper (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSBig Dog52"Trooper (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSBig Dog60"Trooper (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSBill YoadN/AX3000 Stand On BlowerDTHZBEXACT FITCUB CADET48"Pro Z 548 (S00 Series)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 554 (S00 Series)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 550 (S00 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 750 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 750 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro Z 792 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet74"Pro X 668 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro X 664 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro X 666 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro K 666 (Stand On)DTHLG-UNI<					
Big Dog52"Trooper (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSBig Dog60"Trooper (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSBilLY GOATN/AX3000 Stand On BlowerDTHXBEXACT FITBilly GoatN/AZ3000 Stand On BlowerDTHZBEXACT FITCUB CADET48"Pro Z 544 (S00 Series)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 554 (S00 Series)DTHMD-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 560 (S00 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 760 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 772 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 772 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro Z 972 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet74"Pro X 648 (stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro X 648 (stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro K 648 (stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES			· · · ·		
Big Dog60"Trooper (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSBILLY GOATN/AX3000 Stand On BlowerDTHXBEXACT FITBilly GoatN/AZ3000 Stand On BlowerDTHXBEXACT FITCUB CADET48"Pro 2 548 (S00 Series)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro 2 554 (S00 Series)DTHMD-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro 2 760 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro 2 772 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro 2 960 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro 2 972 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro X 648 (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro X 648 (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro X 664 (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro X 660 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 336DTHSM-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN					
BILLY GOATN/AX3000 Stand On BlowerDTHXBEXACT FITBilly GoatN/AZ3000 Stand On BlowerDTHZBEXACT FITCUB CADET48"Pro Z 548 (500 Series)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro Z 554 (500 Series)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 560 (500 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 760 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 772 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 772 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 972 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 648 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro X 648 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro X 648 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro HW 336DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro HW 348DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CAS					
Billy GoatN/AZ3000 Stand On BlowerDTHZBEXACT FITCUB CADET48"Pro Z 548 (500 Series)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro Z 550 (500 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 760 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 760 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro Z 772 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 972 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 972 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 972 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 648 (stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro X 660 (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro HW 336DTH			,		
CUB CADET48"Pro Z 548 (500 Series)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro Z 554 (500 Series)DTHMD-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 560 (500 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 760 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro Z 772 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 960 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro Z 972 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro Z 972 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro X 648 (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro X 648 (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS <td< td=""><td></td><td></td><td></td><td></td><td></td></td<>					
Cub Cadet54"Pro Z 554 (500 Series)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 560 (500 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 772 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro Z 772 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 960 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro Z 972 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro Z 4972 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro X 648 (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro HW 336DTHSM-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 354DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSEncore36" </td <td></td> <td></td> <td></td> <td></td> <td></td>					
Cub Cadet60"Pro Z 560 (500 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 760 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro Z 772 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 960 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro Z 972 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro X 648 (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro X 648 (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet36"Pro HW 336DTHSM-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet36"Pro HW 336DTHMD-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro HW 348DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSENCORE32"Rage (stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (stand On)			· · ·		
Cub Cadet60"Pro Z 760 (700 series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro Z 772 (700 series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 960 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro Z 972 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro X 648 (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro X 654 (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet36"Pro HW 336DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro HW 354DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)					
Cub Cadet72"Pro Z 772 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 960 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro Z 972 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro X 648 (stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro X 654 (stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 654 (stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet36"Pro HW 336DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro HW 348DTHMD-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 354DTHMD-UNITELESCOPIC CROSS BAR SPAN 20-36 INCHES BETWEEN CASTOR WHEELSENCORE32"Rage (stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (stand On)DTHSM-UNI <td></td> <td></td> <td>· · ·</td> <td></td> <td></td>			· · ·		
Cub Cadet60"Pro Z 960 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro Z 972 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro X 648 (stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro X 654 (stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet36"Pro HW 336DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro HW 348DTHMD-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 354DTHMD-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSENCORE32"Rage (stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (stand On)DTHMD-UNITELESCOPIC C			, , , , , , , , , , , , , , , , , , ,		
Cub Cadet72"Pro Z 972 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro X 648 (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro X 654 (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet36"Pro HW 336DTHMD-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro HW 348DTHMD-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 354DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS			Pro Z 772 (700 Series)	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Cub Cadet48"Pro X 648 (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro X 654 (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet36"Pro HW 336DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro HW 348DTHMD-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 354DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSENCORE32"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS	Cub Cadet		Pro Z 960 (900 Series)	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Cub Cadet54"Pro X 654 (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet36"Pro HW 336DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro HW 348DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 354DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSENCORE32"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS	Cub Cadet		Pro Z 972 (900 Series)	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Cub Cadet60"Pro X 660 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet36"Pro HW 336DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro HW 348DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 354DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSENCORE32"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS	Cub Cadet	48"	Pro X 648 (Stand On)	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Cub Cadet36"Pro HW 336DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro HW 348DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 354DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSENCORE32"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS	Cub Cadet	54"	Pro X 654 (Stand On)	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Cub Cadet48"Pro HW 348DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 354DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSENCORE32"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS	Cub Cadet	60"	Pro X 660 (Stand On)	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Cub Cadet54"Pro HW 354DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSENCORE32"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS	Cub Cadet	36"	Pro HW 336	DTHSM-UNI	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
ENCORE32"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS	Cub Cadet	48"	Pro HW 348	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Encore36"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS	Cub Cadet	54"	Pro HW 354	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Encore48"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHMD-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS	ENCORE	32"	Rage (Stand On)	DTHSM-UNI	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
Encore 52" Rage (Stand On) DTHMD-UNI TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS	Encore	36"	Rage (Stand On)	DTHSM-UNI	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
	Encore	48"	Rage (Stand On)	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Encore 60" Rage (Stand On) DTHI G-UNI TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS	Encore	52"	Rage (Stand On)	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
	Encore	60"	Rage (Stand On)	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
EXMARK ALL Navigator DTHWALL EXACT FIT	EXMARK	ALL	Navigator	DTHWALL	EXACT FIT
Exmark 36" Vantage DTHSM-UNI TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS	Exmark	36"	Vantage	DTHSM-UNI	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
Exmark 48" Vantage DTHMD-UNI TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS	Exmark	48"	Vantage	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Exmark 52" Vantage DTHMD-UNI TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS	Exmark	52"	Vantage	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Exmark 60" Vantage DTHLG-UNI TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS	Exmark	60"	Vantage	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Exmark 32" Staris E Series NOT CONFIRMED PLEASE CALL WITH MEASUREMENT BETWEEN CASTOR WHEELS	Exmark	32"	Staris E Series	NOT CONFIRMED	PLEASE CALL WITH MEASUREMENT BETWEEN CASTOR WHEELS

		0. · F 0 ·		
Exmark	36"	Staris E Series	NOT CONFIRMED	TELESCOPIC CROSS BAR SPAN 17-22 INCHES BETWEEN CASTOR WHEELS
Exmark	44"	Staris E Series	DTHXSM-UNI	TELESCOPIC CROSS BAR SPAN 17-22 INCHES BETWEEN CASTOR WHEELS
Exmark	44"	Radius E Series	NOT CONFIRMED	PLEASE CALL WITH MEASUREMENT BETWEEN CASTOR WHEELS
Exmark	48"	Radius E Series	DTHMD-4852EXR	48-52" EXMARK RADIUS INCLUDES TELESCOPIC CROSS BAR SPAN 26-36 & BRACKETS
Exmark	52"	Radius E Series	DTHMD-4852EXR	48-52" EXMARK RADIUS INCLUDES TELESCOPIC CROSS BAR SPAN 26-36 & BRACKETS
Exmark	60"	Radius E Series	NOT CONFIRMED	PLEASE CALL WITH MEASUREMENT BETWEEN CASTOR WHEELS
Exmark	ALL	Lazer	CALL	NEED MEASUREMENTS AND PICTURES TO PROCEED W/ PROPER FITMENT
FERRIS	61"	IS3200 (Except Midnight)	DTHFER-1	EXACT FIT
Ferris	72"	IS3200 (Except Midnight)	DTHFER-1	EXACT FIT
Ferris	61"	IS2600	DTHFER-5	EXACT FIT
Ferris	52"	IS2100	DTHFER-5	EXACT FIT
Ferris	61"	IS2100	DTHFER-5	EXACT FIT
Ferris	52"	ISX800	DTHFER-1	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	61"	ISX800	DTHFER-1	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	52"	IS700	DTHFER-3	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	61"	IS700	DTHFER-3	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	44"	IS600	DTHFER-3	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	48"	IS600	DTHFER-3	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	61""	IS600	DTHFER-3	EXACT FIT - REQUIRES ADDITIONALHOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	61"	F320	DTHFER-1	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	72"	F320	DTHFER-1	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	61"	F210	DTHFER-3	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	48"	F160	DTHFER-3	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	52"	F160	DTHFER-3	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	36"	F60	DTHFER-3	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	36"	SRS Z1	*DTHFER-2	EXACT FIT FOR 36" FERRIS Z1
Ferris	48"	SRS Z1	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Ferris	48"	SRS Z2	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Ferris	52"	SRS Z2	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Ferris	61"	SRS Z2	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Ferris	52"	SRS Z3	DTHFER-4	EXACT FIT
Ferris Ferris	52" 61"	SRS Z3 SRS Z3	DTHFER-4 DTHFER-4	EXACT FIT
	-			

Ferris	72"	F800X	DTHALL-HD	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Ferris	61"	Pro Cut S	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Ferris	48"	FW35	DTHALL-HD	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Ferris	52"	FW35	DTHALL-HD	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Ferris	61"	FW35	DTHALL-HD	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Ferris	36"	FW25	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Ferris	48"	FW25	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Ferris	N/A	FB2000 (Stand On Blower)	DTHXB	EXACT FIT
Ferris	N/A	FB3000 (Stand On Blower)	DTHZB	EXACT FIT
Ferris	ALL	ISX3300, 2200	DTHFER-6 (Coming Soon)	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
GRAVELY	32"	Pro Stance	COMING SOON	
Gravely	36"	Pro Stance	COMING SOON	
Gravely	48"	Pro Stance	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Gravely	52"	Pro Stance	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Gravely	60"	Pro Stance	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Gravely	52"	Pro Turn 400	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Gravely	60"	Pro Turn 400	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Gravely	72"	Pro Turn 400	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Gravely	52"	Pro Turn 200	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Gravely	60"	Pro Turn 200	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Gravely	72"	Pro Turn 200	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Gravely	60"	Pro Turn Mach 1	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Gravely	48"	Pro Turn Z & ZX	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Gravely	52"	Pro Turn Z & ZX	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Gravely	60"	Pro Turn Z & ZX	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Gravely	44"	ZT HD	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Gravely	48"	ZT HD	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Gravely	52"	ZT HD	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Gravely	60"	ZT HD	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
HURRICANE	N/A	X3 Stand On Blower	DTHXB	EXACT FIT
Hurricane	N/A	Z3 Stand On Blower	DTHZB	EXACT FIT
HUSQVARNA	48"	Z548	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Husqvarna	54"	Z554	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS

Husqvarna	60"	Z560	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Husqvarna	72"	Z572	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Husqvarna	54"	V554 (Stand On)	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Husqvarna	48"	V548 (Stand On)	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
HUSTLER	54"	Super Z & Super Z Hyper Drive	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Hustler	60"	Super Z & Super Z Hyper Drive	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Hustler	66"	Super Z & Super Z Hyper Drive	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Hustler	72"	Super Z & Super Z Hyper Drive	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Hustler	36"	Trimstar	DTHSM-UNI	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
Hustler	48"	Trimstar	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Hustler	54"	Trimstar	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Hustler	60"	Trimstar	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Hustler	60"	Z Diesel	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Hustler	72"	Z Diesel	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Hustler	36"	Super S (Stand On)	DTHALL-HD	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Hustler	48"	Super S (Stand On)	DTHALL-HD	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Hustler	52"	Super S (Stand On)	DTHALL-HD	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Hustler	60"	Super S (Stand On)	DTHALL-HD	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
JOHN DEERE	36"	Quick Trak 636M (Stand On)	*DTHJD-636	EXACT FIT FOR JD 636 MOWER (16.5" NON TELESCOPIC CROSS BAR)
John Deere	48"	Quick Trak 648M (Stand On)	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
John Deere	52"	Quick Trak 652M (Stand On)	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
John Deere	52"	652E (Stand On Fix Deck)	DTHWRI-4861FD	48-61" FIXED DECK MOWERS INCLUDES TELESCOPIC CROSS BAR SPAN 31-44"& BRACKETS
John Deere	48-54"	Z700 Series	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
John Deere	60"	Z700 Series	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
John Deere	48-72"	Z800 Series w/o weight kit	DTHJD-Z900	EXACT FIT FOR MOWER WITHOUT WEIGHT KIT
John Deere	48-72"	Z800 Series with weight kit	DTHJD-Z900WK	EXACT FIT FOR MOWER WITH WEIGHT KIT
John Deere	48-72"	Ztrak 900 Series w/o weight kit	DTHJD-Z900	EXACT FIT FOR MOWER WITHOUT WEIGHT KIT
John Deere	48-72"	Ztrak 900 Series with weight kit	DTHJD-Z900WK	EXACT FIT FOR MOWER WITH WEIGHT KIT
КИВОТА	48"	Z400 Series	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Kubota	54"	Z400 Series	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Kubota	60"	Z400 Series	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Kubota	48"	Z700 Series	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Kubota	54"	Z700 Series	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Kubota	60"	Z700 Series	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS

REDMAX	54"	CZT Series	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Redmax	60"	CZT Series	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Redmax	72"	CZT Series	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
SCAG	52"	Turf Tiger II	DTHLG-UNI+2	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Scag	61"	Turf Tiger II	DTHLG-UNI+2	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Scag	72"	Turf Tiger II	DTHLG-UNI+2	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Scag	48"	Cheetah	DTHMD-U2X2	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Scag	52"	Cheetah	DTHMD-U2X2	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Scag	61"	Cheetah	DTHLG-UNI+2	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Scag	72"	Cheetah	DTHLG-UNI+2	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Scag	48"	Tiger Cat II	DTHMD-UNI+1	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Scag	52"	Tiger Cat II	DTHMD-UNI+1	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Scag	61"	Tiger Cat II	DTHLG-UNI+1	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Scag	36"	V-Ride I	DTHSM-VR1	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
Scag	48"	V-Ride I	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Scag	52"	V-Ride I	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Scag	61"	V-Ride I	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Scag	36"	V-Ride II	*DTHSG-36VR2	EXACT FIT FOR 36" SCAG V-RIDE 2 MOWERS
Scag	48-52"	V-Ride II	*DTHSG-4852VR2	EXACT FIT FOR 48-52" SCAGE V-RIDE 2 MOWERS
Scag	61"	V-Ride II	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Scag	36"	SWZT	DTHSM-UNI	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
Scag	48"	SWZT	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Scag	52"	SWZT	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Scag	61"	SWZT	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
SPARTAN	48"	RZ Series	DTHMD-U2X2	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Spartan	54"	RZ Series	DTHMD-U2X2	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Spartan	61"	RZ Series	DTHLG-U2X2	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Spartan	54"	RT Series	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Spartan	61"	RT Series	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Spartan	54"	SRT Series	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Spartan	61"	SRT Series	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
TORO	36"	Grandstand (Stand On)	DTHSM-UNI	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
Toro	40"	Grandstand (Stand On)	DTHSM-U2X2	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
Toro	48"	Grandstand (Stand On)	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS

Toro	52"	Grandstand (Stand On)	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Toro	ALL	Z Master	CALL	NEED MEASUREMENTS AND PICTURES TO PROCEED W/ PROPER FITMENT
Toro	ALL	8000 Series	DTHWALL	EXACT FIT
Toro		Multi Force	DTHMF	EXACT FIT
WALKER	ALL	Model S	DTHWALL	EXACT FIT
Walker	ALL	Model C	DTHWALL	EXACT FIT
Walker	ALL	Model T	DTHWALL	EXACT FIT
Walker	ALL	Model D	DTHWALL	EXACT FIT
WRIGHT	ALL	Rapid Height (Stand On)	DTHALL-HD	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Wright	ALL	Stander I "Intensity" (Stand On)	DTHALL-HD	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Wright	ALL-1st GEN	Stander X - 1st GEN (Stand On)	DTHALL-HD	FIRST GENERATION STANDER X WITH 1.5"X2" CROSS BAR
Wright	ALL-2nd GEN	Stander X - 2nd GEN (Stand On)	*DTHWRI-XZK	SECOND GENERATION STANDER X WITH 1.5"X2.5" CROSS BAR - EXACT FIT
Wright	ALL	Stander ZK (Stand On)	*DTHWRI-XZK	EXACT FIT
Wright	36"	Stander Fixed Deck (Stand On)	*DTHWRI-3642FD	36-42" FIXED DECK MOWERS INCLUDES TELESCOPIC CROSS BAR SPAN 20-26"& BRACKETS
Wright	42"	Stander Fixed Deck (Stand On)	*DTHWRI-3642FD	36-42" FIXED DECK MOWERS INCLUDES TELESCOPIC CROSS BAR SPAN 20-26"& BRACKETS
Wright	48"	Stander Fixed Deck (Stand On)	*DTHWRI-4861FD	48-61" FIXED DECK MOWERS INCLUDES TELESCOPIC CROSS BAR SPAN 31-44"& BRACKETS
Wright	52"	Stander Fixed Deck (Stand On)	*DTHWRI-4861FD	48-61" FIXED DECK MOWERS INCLUDES TELESCOPIC CROSS BAR SPAN 31-44"& BRACKETS
Wright	61"	Stander Fixed Deck (Stand On)	*DTHWRI-4861FD	48-61" FIXED DECK MOWERS INCLUDES TELESCOPIC CROSS BAR SPAN 31-44"& BRACKETS
Wright	48"	Stander B (Stand On)	DTHALL-HD	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Wright	52"	Stander B (Stand On)	DTHALL-HD	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Wright	36"	Sport I	DTHALL-HD	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Wright	48"	Sport X	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Wright	52"	Sport X	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Wright	61"	Sport X	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Wright	ALL	Sport RH	DTHALL-HD	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Wright	ALL	Sentar	DTHALL-HD	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Wright	ALL	Sentar Sport	DTHALL-HD	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Wright	48"	ZTO	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Wright	52"	ZTO	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Wright	61"	ZTO	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Wright	52"	MMZ	DTHMD-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Wright	61"	MMZ	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
ZRATOR	ALL	ALL	*DTH-ZRA	IF YOU CURRENTLY HAVE A ZRATOR MOUNT INSTALLED ONTO YOUR MOWER
				DTH-ZRA IS A ZRATOR ADAPTER HITCH USED TO CONVERT HD ZRATOR MOUNT INTO A

	SINGLE HITCH RECEIVER FOR SINGLE HITCH D'TTACH ATTACHMENTS AND NO ADDITIONAL HITCH MOUNT IS REQUIRED
*NEW PRODUCT	REVISED 2/9/21