


Instructions

LINER


The liner is made up of 4 pieces. Your helmet will come with extra pieces of foam (shims). If the helmet does not feel tight enough, you can add shims to the liner. If the helmet is too tight, you can take shims out that are in the liner already.

COLLAR


The collar needs to be adjusted for each person. It is adjusted by pulling and setting a new knot on the cord by the ladder part of the buckle. (Picture 1)



The best way to adjust the collar is pulling the knotted cord as shown in picture 2. Pull tension on the cord, tightening the collar just enough to slide it over your head. Note the location and tighten a new knot. Later, once you are happy with the fit, you may trim down any slack.



Once you have adjusted the collar, put the helmet on and snap the buckle in place. If you still feel that the collar needs to be tighter around but do not want to adjust the collar any further, you are able to twist the ladder part of the buckle to make it a bit tighter before snapping the buckle. (Picture 3)



LENS AND LOCK

The lens locking mechanism is spring loaded and has a pin that must completely clear before opening the lens. The easiest way to open the lens is while wearing the helmet. Simply pull out on both sides, away from your face, enough to clear the pins and rotate upward to open the lens. (Picture 4)

