



RECORDER CARRIER

Product No. 0701-0556XX-DA

The **Recorder Carrier** assembly is designed to carry pressure and temperature recorders used to document subsurface pressure and temperature inside or outside the flow passage during a well test.

The inside recorder slots are designed to hold the gauges which monitor the pressure and temperature of the inside flow passage during a well test. The outside recorder slots are designed to carry the gauges to record the subsurface data in one or two subsurface zones. If the carrier is run directly below the upper inflate packer, the test interval outside the flow passage is recorded. If the carrier is run above the upper inflate packer the pressures and temperatures in the annulus are recorded. Each **Recorder Carrier** assembly holds two inside and two outside recorders.

