


Schematic below is on the back of the BP cover which looks like this

J43 TO J13 (BLOWER ON J14)  
IN SETUPS 3, 5, 9, 11, 12, 17, 18



Press here to release

