## BC 3-5 REPLACING MIXING ARM MOTOR:




1. If you want to replace the mixing motor, first open the door under the cooling tray.

2.SECOND, THERE ARE 4 SCREWS FIXED TO THE COOLING TRAY, YOU NEED LOOSEN THEM.



3. THIRD, REMOVE THE COOLING TRAY FROM THE MACHINE.



- 4.THE LAST, LOOSE FOUR SCREWS AND REMOVE THE MOTOR FROM THE COOLING
- **5.A**LWAYS TAKE PICTURES OF WIRING BEFORE REMOVING ANY WIRES
- **6.R**ECONNECT THE WIRES JUST AS IT WAS BEFORE, AND THEN PUT THE COOLING TRAY ON THE ROASTER