

Instructions for use:

Block all passengers from escalator to be cleaned before starting procedure!

- 1) Mount the cleaning pad with the white side to the back of the device.
- 2) Pour the specified amount of TREAD CLEAN solution into the saturation trough. Place the device into the trough and compress firmly with a pumping action, until the pad is saturated and the TREAD CLEAN is fully absorbed. Or, step on the device gently to compress the sponge material to absorb all the solution more rapidly and completely.
- 3) Place the device and cleaning pad onto the oncoming escalator treads ahead of the combs. Allow the device to align with the treads, abut the combs and drop into position. Check to make sure the pads teeth are aligned and inside the treads grooves. Apply moderate downward pressure and allow 3 to 5 minutes of cleaning, until the pad is loaded with dirt, or the escalator treads are clean. Repeat as necessary.

Important Safety Tips:

- Never stand or step on the device while it is on the escalator or in operation.
- Keep fingers, loose clothing, hair and jewelry away from device during use.
- Make sure the escalator is completely dry before allowing passengers on.
- Always use the handle to place and remove the device from the escalator.

Cleaning Solution Information:

Only use REN™ TREAD CLEAN as it will not damage the various finishes found on escalators. Other cleaning solutions may damage the pads and lower their efficiency. Other solutions may also not properly emulsify the dirt and grease, lowering the effectiveness, reusability and longevity of the pads.

A 10:1 dilution ratio is recommended for all procedures

For a 24" pad -- use 16-oz of diluted Tread Clean solution

For a 32" pad -- use 20-oz of diluted Tread Clean solution

For a 40" pad -- use 24-oz of diluted Tread Clean solution

Tips for more effective escalator cleaning, maintenance and safety:

- Initial restorative cleaning is highly recommended before a regularly scheduled maintenance regiment using the REN system is implemented.
- For severely neglected escalators, a comprehensive deep cleaning may be necessary prior to implementation of scheduled REN cleaning.
- Escalator cleaning schedules should be at the same or similar frequency as the flooring leading up to or away from those escalators.
- Have your staff properly trained on the REN system. Document and implement a safety procedure for emergency spill deployment.

How do I clean really tough stains?

Pre-saturating the tread steps prior to cleaning is highly recommended for stubborn or difficult stains. Spot spray diluted TREAD CLEAN directly on just those areas in need of treatment. DO NOT oversaturate. Allow a few minutes dwell time for the solution to loosen and emulsify the stains.

- * For tar or gum, a specialized cleaner may be required. Follow up with a thorough rinsing and cleaning procedure using the REN system.

How do I know when the cleaning pads need to be replaced?

REN recommends approximately 3 to 5 minutes per cleaning cycle before removing and washing/reusing or disposing of the cleaning pads. A visual inspection may be used to determine the pads condition.

How often should I clean my escalators?

Escalator cleaning frequency depends on the amount of traffic and dirt an escalator accumulates. Escalator cleaning frequency should match that of the flooring areas leading up to or away from that escalator.

What can I do about the risers?

The risers receive most of the dirt that accumulates on them from the treads above. If the treads above are cleaned frequently and regularly, the risers will stay much cleaner, much longer. If the risers are severely stained, a separate or additional procedure may need to be utilized. Once the risers are cleaned and after the treads have been cleaned, regular scheduled cleaning with the REN system will keep the entire escalator cleaner longer.