



1. Before opening the turn-panel, the slider at the locking point needs to be unlocked. The turn-panel can be opened using the pull-rod in on the turn-panel.
2. The next panel can be taken upside the middle of the panel and you can slide it against the opened panel and than it can be turned to open it.
3. With all the other panels you can do the same.
4. Panels you need to slide along an angled track please move carefully over the corners and to open them it is the same process as before at the 2. and 3. point.
5. After closing the last panel, take care for the locking points. The top snatch needs to lock the panel. And push the slider in the bottom of the turn-panel into the locking position.

Attention:

At these kind of glazing, the edges of the glass are not protected. A contact between the glass and hard edges or materials can burst the glass. If it is windy, you need to close the system to make sure, nothing will get damaged.

Service notes:

The fitting parts are maintenance-free.

Care instructions:

1. The Polyamide parts of the system can be atomized one time a year with for example silicone-spray to keep them in a good condition.
2. For the aluminum-profiles, we suggest, use warm water and a mild soap. Keep the damp cloth clean, otherwise you can damage the surface.
3. For the glass please take a standard cleaning agent for glass or a mild soap.
4. To clean the outer surface, you can open up the panels