

1. FLEXIBLE GPS TRACKING AND TELEMATICS – WITH IRIDIUM OPTION

The **Allrounder** is a compact 3G (*NextG*) GPS tracking device with a variety of inputs and outputs to cater for the most demanding applications, and a FlexiCard slot allowing for the most flexible expansion options in the industry – *including satellite modem, WiFi and others.*



1.1. Allrounder Hardware Features

Hardware Features							
Compact rugged housing	<p>Made of sturdy UV resistant plastic the housing clips together for easy assembly, and has 2 convenient mounting tabs.</p> <p>Dimensions: 125mm x 65mm x 30mm Weight: 250 grams</p>						
Connector	<p>24 pin connector</p> <p>A basic harness is supplied as standard with the Allrounder.</p> <p>See the Allrounder user manual for connector pin details.</p>						
Automotive power	<table border="1"> <tr> <td>Voltage</td> <td>8V to 45V DC</td> </tr> <tr> <td>Operating Current</td> <td>15mA average (<i>battery fully charged</i>) 135mA average (<i>battery charging</i>)</td> </tr> <tr> <td>Sleep Current</td> <td><1mA</td> </tr> </table> <p>The Allrounder passes stringent automotive power ‘<i>load dump</i>’ tests to ensure that it will continue to operate in the harshest electrical systems. A built-in self-resetting fuse makes installation easy and safe.</p>	Voltage	8V to 45V DC	Operating Current	15mA average (<i>battery fully charged</i>) 135mA average (<i>battery charging</i>)	Sleep Current	<1mA
Voltage	8V to 45V DC						
Operating Current	15mA average (<i>battery fully charged</i>) 135mA average (<i>battery charging</i>)						
Sleep Current	<1mA						
Operating Temperature	<p>-30°C to +85°C ¹</p> <p>1) On external power.</p> <p>Below 0°C the standard internal backup battery’s ability to deliver sufficient power to operate the cellular modem is reduced. Below 0°C and above +45°C the internal backup battery will not be charged as a safety precaution due to dangers associated with charging batteries at extreme temperatures.</p> <p>For battery, powered tracking in extreme temperatures enquire about our Outback tracker with extended temperature range battery options.</p>						
High sensitivity GPS	UBLOX MAX8 GPS module						

	<p>Supports concurrent GLONASS and other GNSS systems 72 channel high sensitivity receiver -167dBm industry leading tracking performance Battery backed up for optimal hot-start performance AssistNow Offline aiding data for extremely fast time-to-first-fix and performance in urban canyon environments</p>						
Concurrent GPS and GLONASS	<p>The Allrounder supports position tracking using both the American GPS satellites and the Russian GLONASS system concurrently. This results in amazingly fast and accurate tracking with double the number of satellites available for use.</p>						
Low noise GPS amplifier	<p>GPS signals are boosted by a special low-noise amplifier (<i>LNA</i>) This allows the Allrounder to operate where normal units will fail to receive GPS signal</p>						
3G (NextG)	<p>The Allrounder can be manufactured for specific markets around the world with cellular modem modules approved by all the major networks</p> <hr/> <table> <tr> <td>3G Modem – EU</td> <td>850 / 900 / 2100 EMEA / APAC / Latin America</td> </tr> <tr> <td>3G Modem - NA</td> <td>850 / 1900 / AWS North America</td> </tr> <tr> <td>3G Modem (Global Option)</td> <td>800 / 850 / 900 / AWS / 1900 / 2100 Global coverage at a higher cost</td> </tr> </table> <hr/> <p>*enquire for other bands and LTE / 4G options</p>	3G Modem – EU	850 / 900 / 2100 EMEA / APAC / Latin America	3G Modem - NA	850 / 1900 / AWS North America	3G Modem (Global Option)	800 / 850 / 900 / AWS / 1900 / 2100 Global coverage at a higher cost
3G Modem – EU	850 / 900 / 2100 EMEA / APAC / Latin America						
3G Modem - NA	850 / 1900 / AWS North America						
3G Modem (Global Option)	800 / 850 / 900 / AWS / 1900 / 2100 Global coverage at a higher cost						
Certifications	CE, A-Tick, ICASA, others in progress						
Iridium SBD	<p>Global coverage – anywhere in the world.</p> <p>The Allrounder can be fitted with an Iridium SBD module that allows it to communicate via the Iridium satellite network. The Allrounder will automatically switch over to using Iridium communications when out of range of the cellular networks.</p>						
WiFi	<p>Save SIM data costs.</p> <p>The Allrounder can be fitted with a WiFi FlexiCard – allowing it to communicate on a WiFi network.</p>						
Internal Antennae*	<p>Internal GPS and cellular antenna Having the primary antennae inside the housing makes for very simple and quick installation. The Allrounder has had its antennae tuned by the top laboratories to ensure optimal performance. <i>*Iridium modem and other wireless FlexiCards may require an external antenna</i></p>						
Backup battery	<p>The standard 800mAh LiPo backup battery allows the Allrounder to operate when external power is removed for up to 4 days, depending on the amount of movement. Optional HUGE battery pack of 1800mAh available on special order.</p>						
5 x Digital Inputs	<p>1 x Ignition line 4 x digital inputs with configurable pull-up / pull-down</p>						

	Numerous configuration options including switches, duress/panic alerts, pulse counting
2 x Digital Outputs	2 x switched ground digital outputs, easily wired up to switch external lights, relays, buzzers, sirens, motors and other devices Can be used to immobilise a vehicle
Internal Buzzer	Audible alert without requiring the installation of an external buzzer. Can be used for speeding alerts, harsh driving alerts, reminders to swipe RFID tags, error conditions and other events
Diagnostic LED	The diagnostic LED makes it easy to see if the device is operating correctly
3 axis accelerometer	The 3-axis accelerometer allows the Allrounder to detect harsh driving events (<i>harsh acceleration, braking and cornering</i>) and this information can be used to monitor driver behaviour and unsafe driving. It also allows the Allrounder to go to ' <i>sleep</i> ' when not moving, resulting in extremely low standby current.
iButton	Communicate with common one-wire iButton devices
RS232	RS232 receive and transmit allow the Allrounder to communicate with external RS232 devices. These can include fuel monitoring, Garmin FMI, tyre pressure monitoring The RS232 interface can also be used to configure the device and to test and debug.
Switched 5V out	The Allrounder can provide power to external peripherals via this 5V power line, allowing for easy installation and doing away with the need for additional external power supplies. Maximum current: 300mA
DMCAN peripheral port	iTRAKassets has a range of peripherals that connect to the Allrounder via the DMCAN peripheral port. Peripherals such as the RFID Driver ID reader, 5 digit keypad, data console and RF gateway use the DMCAN port.
Flash memory	The Allrounder has sufficient memory to store over 50,000 records in its flash memory. Normally the data will be sent to the server immediately but if the device is out of range then there is sufficient space to ensure that no data is lost – for many weeks of driving! The flash memory is also used to store parameters, GPS aiding data, accident data, driver lists, geo-fences and other important information that needs to be securely stored.
FlexiCard Expansion Slot	The Allrounder has one FlexiCard slot. This card slot allows the device to be upgraded to support extra functionality: <ul style="list-style-type: none"> • Iridium satellite modem • WiFi data transfer • Bluetooth • Radio gateway • SDI12 • RS485 • Additional RS232 ports

	<ul style="list-style-type: none"> iTRAKassets partners can design custom cards by request <p>The innovation of FlexiCards allows the Allrounder to be the most flexible telematics device available on the market.</p>
6 x FlexiCard IO	The FlexiCard slot is connected to 6 pins on the Allrounder connector. This allows the cards to provide functionality to the outside world via the connector pins.
J1939	Coming soon
Garmin FMI	Coming soon



1.2. Allrounder Firmware Features

Firmware Smarts	
Auto-APN	Auto-APN allows the Allrounder to analyse the SIM card and select the correct APN details from a list that is pre-loaded in the device's firmware. This means that the Allrounder can be shipped world-wide without requiring specialist setup for SIMs.
Text Message Setup	The Allrounder can also be sent text messages to setup the APN, server and other details
Multi-APN	The Allrounder can be configured to roam across multiple networks and to automatically use the different APN details for the roaming networks.
AssistNow Offline	The Allrounder will track successfully where other devices just give up. This fantastic technology allows the GPS to predict which satellites are in orbit above it and to dramatically reduce the time-to-first-fix of the GPS, and the overall performance of the GPS, especially in 'urban canyon' or forested environments.
Flexible Logging Parameters	<p>The Allrounder trip logging is flexible and can be configured to log based on a variety of parameters including:</p> <ul style="list-style-type: none"> Elapsed time Distance travelled Change in heading Change in speed On Stationary Accelerometer events (<i>harsh driving</i>)

Accident and Rollover Detection	The Allrounder uses the built-in accelerometer to detect high-G impacts such as accidents and rollovers and reports these events to the server for emergency alerting.
Harsh Driving	<p>The Allrounder automatically calibrates its built-in 3-axis accelerometer and uses this to detect harsh driving events:</p> <ul style="list-style-type: none"> • Excessive acceleration • Harsh braking • Cornering at speed <p>These events are logged in the Allrounder along with additional event statistics that allow back-end server platforms to perform sophisticated driver profiling and scoring.</p>
Accident Data	The Allrounder keeps a second-by-second ' <i>blackbox</i> ' recording of valuable GPS and accelerometer data for a two-hour window. This data can be automatically uploaded to the server when an accident is detected, or it can be requested manually.
Driver Identification	<p>The Allrounder supports multiple ways to identify a driver:</p> <ul style="list-style-type: none"> • RFID reader and a card or key-fob • 5-digit key-pad to enter a PIN code • Console with built-in RFID reader • iButton 1-wire reader
Driver Lists	<p>The Allrounder can be updated from the server with lists of Drivers that can drive the vehicle that it is installed in. When a driver or operator registers on the Allrounder it will check the Driver List to see if that person is authorised to drive the vehicle. The list also includes information about the driver such as whether they can perform supervisor functions.</p> <p>The Allrounder can be installed to immobilise a vehicle and only allow authorised drivers / operators to drive it, or to annoy an unauthorised driver with a loud buzzer.</p>
Geo-Fences	<p>The Allrounder has the capacity to hold hundreds of geo-fences that can be downloaded to it from the server. The Allrounder can use this geo-fence information to:</p> <ul style="list-style-type: none"> • Implement arrival and departure alerts • Implement speeding zones with audible warning alerts • Implement '<i>No-go</i>' and '<i>Keep-out</i>' areas • Automatically control outputs, for example to switch on warning lights when inside a special area • Warn drivers when approaching dangerous intersections • Disable data communications within intrinsically safe areas
Emulated Ignition	<p>This setting allows the Allrounder to determine that a trip has started based on accelerometer and GPS data and to automatically set the '<i>ignition</i>' input on the device to emulate the ignition line.</p> <p>This means that the Allrounder can be installed with the option of not wiring in the ignition line and '<i>emulating</i>' the ignition based on movement.</p>

Run Detect

This setting allows the **Allrounder** to monitor the system voltage and to detect changes in the voltage that indicate if the engine is running or not.

1.3. FlexiCard Expansion

A FlexiCard is a small PCB expansion card that has circuitry on it to extend the functionality of the **Allrounder**. This can range from additional communication options (eg *Iridium, WiFi, Bluetooth*) through to specialised interfaces (eg *SDI-12, J1939, Modbus*). A variety of these cards already exist and **iTRAKassets** can design custom cards for specific requirements.

The **Allrounder** has one FlexiCard slot, with six pins of the 24 pins on the connector made available for use by the FlexiCard circuitry. The **Allrounder** housing also accommodates a SMA connector for functions where the FlexiCard might require an external antenna.



FlexiCard Options	
Iridium Satellite Modem	<p>Track and communicate from anywhere in the world!</p> <p>The Iridium FlexiCard allows the Allrounder to communicate on the global Iridium SBD network. The card uses the latest Quake 9603 Iridium modem and an external Iridium antenna.</p> <p>The Allrounder will automatically switch over from using the cellular network to sending data on the Iridium SBD network when there is no cellular coverage.</p>
WiFi	Transmit data over a WiFi network. Useful for customers that don't require cellular communications and the associated on-going costs.
Bluetooth	Communicate with Bluetooth devices via a data connection.
RF Gateway	Provides the interface to allow the Allrounder to receive data from iTRAKassets low cost range of RF asset tags and wireless sensors 868MHz and 900-928MHz options
SDI-12	<p>Allows the Allrounder to manage power and communicate with any SDI-12 sensors.</p> <p>SDI-12 is commonly used in agriculture and sensors include soil moisture probes, temperature probes, EC (<i>electrical conductivity</i>) probes, tipping rain gauges and others.</p>
Temperature (and other I2C Sensors)	<p>Allows the Allrounder to power and communicate with iTRAKassets temperature probes certified accurate to 0.5°C – suitable for monitoring refrigerated storage and transport solutions.</p> <p>The I2C bus allows iTRAKassets to also add other sensors from a range of pressure, humidity, electronic compass, pH and others sensors or I2C products.</p>
RS232	<p>For applications that required extended RS232 connectivity this FlexiCard provides external power control and communications with 2 additional RS232 external devices.</p> <p>Examples include: <i>fuel monitoring systems, tyre pressure monitoring, Garmin FMI, and any other system with an RS232 interface.</i></p>
J1939	coming soon
RS485	coming soon
Custom FlexiCards	iTRAKassets can rapidly develop and prototype custom FlexiCards for special requirements.

1.4. DMCAN Peripheral Expansion

The **Allrounder** interfaces to a range of peripherals that further extend its capabilities.

Peripheral Options

RFID Driver ID Reader



Compact 125kHz RFID Reader reads cards and key-fobs
 5cm typical read range (*can read through plastic / dashboard*)
 Plugs into the DMCAN peripheral plug on the **Allrounder** harness for easy installation
 Includes a LED and buzzer for reminding drivers to swipe their card
 Compatible with the EM4001 RFID standard
 Optional 125kHz HID reader option

5 digit keypad



Compact 5-digit key-pad (*keys 1 through 5*)
 Includes a LED, backlight for night-time input and buzzer
 Use for

- Driver Identification (*using a PIN code*)
- Select the trip type (*business versus private*)
- Map to digital inputs for other functions like panic button, logging point of interest, changing driver state (*on / off duty*) etc.
- Long-press option for alternate functions

Plugs into the DMCAN peripheral plug on the **Allrounder** harness for easy installation

Console



Rugged data entry console

- 4 x 20 character display with backlight
- 12 key sealed keypad
- RFID reader under the keypad
- Built-in buzzer
- Application examples:
 - Operator login with machine pre-check questions
 - Work allocation to project codes and cost codes
 - Login with OH&S questions
 - Time and attendance recording
 - Driver fatigue management
- Firmware can be customised

Plugs into the DMCAN peripheral plug on the **Allrounder** harness for easy installation

RF Gateway

Provides the interface to allow the **Allrounder** to receive data from iTRAKassets low cost range of RF asset tags and wireless sensors
 868MHz and 900-928MHz options
 Transmit and Receive
 Plugs into the DMCAN peripheral plug on the **Allrounder** harness for easy installation

1.5. Device Management – OEM Server

All iTRAKassets devices are fully managed Over-The-Air (OTA) via our OEM Server web interface. The OEM Server seamlessly manages:

- Device firmware – firmware updates can be done remotely
- Network (*administrator*) parameters relating to critical communications
- System parameters, including GPS parameters, IO configuration, logging options and general device behaviour settings
- GPS AssistNow Offline aiding data files
- Remote debugging of devices, including being able to trace data, view detailed debug message logs, and view a live trace of the server debug messages
- Remote disconnect and reboot of devices
- Driver list downloads to devices – this allows for the Driver Identification on the device to check if the RFID tag / username / PIN is valid, and for specific drivers to be allowed to drive / operate particular vehicles, for example based on licences or permits.
- Geo-fence syncing with the devices – this allows the device to do advanced in-cab alerting and monitoring such as geo-fence arrival and departure, speed limit alerting, dangerous intersection warnings, turn on warning lights inside a geo-fence, and disable communications inside intrinsically safe zones such as gas plants.
- Provides a command and message queueing platform to the devices and is incorporated into the remote management and debugging applications

Data Connectors

The OEM Server provides Data Connectors that forward data records on to the software platform of your choice, including iTRAKassets own Telematics Guru and GPS Log Book platforms. More information on the OEM Server can be found at <http://www.itrakassets.com>

If you would like to integrate the **Allrounder** into a software system, then please contact iTRAKassets for more information on our integration protocols.

1.6. Committed to Quality

We take pride in designing each of our products with the goal of providing the best performance and reliability possible in the price range of that product. *'Engineered to outperform'*.

Not all GPS tracking devices operate with the same level of performance or reliability, especially when exposed to extreme conditions in the field. In addition we only use the highest quality parts and the latest assembly and quality control techniques to ensure the reliability and long life of our products.

Every device is individually tested at production, and our batteries are individually tested with full charge / discharge cycle tests before being fitted into our devices.

All iTRAKassets devices are covered by a one year manufacturer's warranty.

1.7. Contact Information

For the latest version of this document plus other product information please visit our website at www.itrakassets.com