



## RFM20-512-50-HSD

### 20-512MHz 50W Class A High Performance Amplifier with High Speed Disable

- ❖ Class A 50W linear amplifier
- ❖ Fast output disable,  $\leq 1\mu\text{sec}$
- ❖ VVA with over 30dB range
- ❖ Analog temperature out
- ❖ High temperature alarm
- ❖ Temperature compensated bias
- ❖ Available with input limiter and/or heatsink and fan



The RFM20-512-50-HSD is a Class A high performance amplifier module, outstanding as a driver stage in military communication or radar systems. It features fast output disable with  $\leq 1\mu\text{sec}$  response time. It exhibits excellent full power and back-off linearity, and utilizes conservatively rated LDMOS transistors for maximum reliability.

#### Specifications

$V_{\text{supply}} = +28\text{VDC}$ ,  $I_{\text{DQ}} = 6.85\text{A}$ ,  $P_{\text{out}} = 50\text{W}$ ,  $T_{\text{base}} = 40^\circ\text{C}$ ,  $Z_{\text{load}} = 50\Omega$

Parameter	Min	Typ	Max	Units
Freq. Range	20		512	MHz
$P_{1\text{dB}}$		>75		W
Input Power		-2	1	dBm
Gain	46	49		dB
Gain Flatness		+/-0.5	+/-1.0	dB
Drain Current		7.3	7.6	A
Efficiency	23	24		%
IRL		-24	-14	dB
$f_2$		-43	-28	dBc
$f_3$		-35	-25	dBc
$\text{IMD}_3$ 50W PEP, $\Delta f=10\text{kHz}$ and $\Delta f=100\text{kHz}$ . See Fig. 2 for 25W PEP.		-38	-32	dBc
Dimensions	3.60 X 6.55 X 1.30 (91.44 X 166.37 X 33.02)			inch (mm)

#### Maximum Ratings

Operation beyond these ratings may damage amplifier.

Parameter	Value
$V_{\text{supply}}$	24-28VDC
Bias Current	6.85A
Drain Current	8.0A
Load Mismatch*	5:1
Housing Base Temperature	65°C
Storage Temperature	-40°C to 85°C

\*All phase angles, 50W forward power, current limited to 8.0A for 5 seconds max.

#### Option Ordering Info

Input limiter	RFM20-512-50-HSD-LIM
Heatsink and fan	RFM20-512-50-HSD-HSF

RF and Microwave Power Technology, LLC • 2380 Solitude Drive • Reno, NV 89511 USA  
(775) 842-3280 • [sales@rfmpt.com](mailto:sales@rfmpt.com) • [www.rfmpt.com](http://www.rfmpt.com)

Specifications contained herein are subject to change without notice.  
RF and Microwave Power Technology, LLC assumes no liability for the use of this information.  
© 2025 RF and Microwave Power Technology, LLC





# RFM20-512-50-HSD

## 20-512MHz 50W Class A High Performance Amplifier with High Speed Disable




Figure 1: RFM20-512-50-HSD Typical Gain @  $P_{out}=50W$ .




Figure 2: RFM20-512-50-HSD Typical  $IMD_3$  @ 50W and 25W PEP,  $\Delta f=10kHz$  and  $\Delta f=100kHz$ .





Figure 4: RFM20-512-50-HSD Typical  $P_{1dB}$  and Safe Operating Area (SOA). The amplifier is capable of delivering much more power than it is safe to generate. Do not exceed the SOA shown above without first contacting RFMPT to discuss your application.

RF and Microwave Power Technology, LLC • 2380 Solitude Drive • Reno, NV 89511 USA  
 (775) 842-3280 • [sales@rfmpt.com](mailto:sales@rfmpt.com) • [www.rfmpt.com](http://www.rfmpt.com)  
 Specifications contained herein are subject to change without notice.  
 RF and Microwave Power Technology, LLC assumes no liability for the use of this information.  
 © 2025 RF and Microwave Power Technology, LLC






**RFM20-512-50-HSD**


**20-512MHz 50W Class A  
High Performance Amplifier  
with High Speed Disable**

**Amplifier Mounting Hole and RF Locations**



RF and Microwave Power Technology, LLC • 2380 Solitude Drive • Reno, NV 89511 USA  
 (775) 842-3280 • [sales@rfmpt.com](mailto:sales@rfmpt.com) • [www.rfmpt.com](http://www.rfmpt.com)  
 Specifications contained herein are subject to change without notice.  
 RF and Microwave Power Technology, LLC assumes no liability for the use of this information.  
 © 2025 RF and Microwave Power Technology, LLC





**RFM20-512-50-HSD**

**20-512MHz 50W Class A  
High Performance Amplifier  
with High Speed Disable**

## Interface Pins and Functions

- 1: VVA** The voltage variable attenuator has a slope of approximately 30dB/volt, from 0.65 to 1.65V. Maximum attenuation is reached by 2.0V. The acceptable control range is 0 to 3.6V. Do not exceed 3.6VDC on this pin. **The VVA control voltage should be set to zero volts during amplifier power up and power down.** Maximum RF input power is +1dBm, without the limiter option. Do not exceed the SOA in Figure 4, with or without the limiter option.
- 2: Temp Alarm** This indicates an over-temp condition, and is set to trip at a housing base temperature of approximately +65°C. It is an open drain output, pulled up internally to +15VDC, and will pull down to 0V at +65°C. The end user may either scale this range to suitable voltages with a simple resistive divider, or use an analog or digital input capable of handling +15VDC. This signal exhibits 5°C of hysteresis, and will reset to +15VDC at approximately +60°C.
- 3: Output Disable** This is active high at +5VDC. It disables the second and output stages of the amplifier, and will reduce full rated output power to near zero\* in  $\leq 1\mu\text{sec}$ . When set to 0VDC, the amplifier will return to full power in approximately 75 $\mu\text{sec}$ .
- \* Due to feedback paths around the second stage and output transistors, there will be a small amount of RF still present at the output even when the output has been disabled, unless the user simultaneously turns off their RF drive source. For additional RF quieting, the VVA may be set to maximum attenuation simultaneously with the Output Disable signal.
- 4: GND** Amplifier ground. Connect to power supply return/ground. Use in parallel with pin #8. A minimum of 20 gauge wire is recommended.
- 5: +28VDC** The nominal supply voltage is +28VDC. As low as +24VDC may be used, with a reduction in  $P_{1\text{dB}}$ , IMD, and harmonics performance. Use in parallel with pin #9. A minimum of 20 gauge wire is recommended.
- 6: Temp Out** This is an analog signal that is a nominal +0.75V at +25°C. It has a positive slope of 10mV/°C with increasing temperature. A temperature gradient and an offset will exist between the temperature reported on this pin and the actual housing base temperature directly under the output transistor. It is up to the end user to properly characterize this signal's response with their chosen cooling configuration.
- 7: MMIC Disable** This is a supplementary disable pin, for additional amplifier quieting at the user's discretion.
- 8: GND** Amplifier ground. Connect to power supply return/ground. Use in parallel with pin #4. A minimum of 20 gauge wire is recommended.
- 9: +28VDC** The nominal supply voltage is +28VDC. As low as +24VDC may be used, with a reduction in  $P_{1\text{dB}}$ , IMD, and harmonics performance. Use in parallel with pin #5. A minimum of 20 gauge wire is recommended.

## Limiter Option

The limiter option significantly impacts amplifier linearity. Please contact RFMPT to learn more.





**20-512MHz 50W Class A  
High Performance Amplifier  
with High Speed Disable**

**Instructions for Amplifier Use**

- 1) If not supplied with a heatsink, apply a layer of high quality thermal grease (Wakefield Type 122 or equivalent) to the underside of the amplifier housing. Thinner is better, but ensure that when mounted to your heatsink, contact across the *entire* module base is made. Gaps and air bubbles will significantly reduce cooling, leading to possible amplifier damage. Use six #6-32 screws to mount the amplifier to your heatsink.
- 2) Guarantee sufficient airflow through the heatsink fins to keep the maximum housing base temperature at or less than that specified in the Maximum Ratings section. Contact RFMPT for details on how to qualify your heatsink's performance, if needed.
- 3) Connect a proper signal source to the RF IN connector, and desired load to the RF OUT connector. Torque connectors to industry standards for the type supplied with the amplifier.
- 4) Connect DC  $V_{supply}$  to pins 5 and 9 of the interface connector. Connect power supply return/ground to pins 4 and 8 of the interface connector. Ensure that  $V_{supply}$  is within the voltage range in the Maximum Ratings section.
- 5) Apply desired signals/monitoring lines to remainder of interface pins. Refer to the Interface Pins and Functions section for signal descriptions, limits, and timing requirements.
- 6) Apply DC power then sufficient RF drive to achieve desired output level. Ensure that the Safe Operating Area (SOA) power level indicated in Figure 4 is not exceeded, or amplifier damage may occur, and will void the warranty.
- 7) To disconnect the amplifier, first remove the RF drive, then DC power, then the RF connections.

Contact the factory at [sales@rfmpt.com](mailto:sales@rfmpt.com) with any questions, or for special options, testing requirements, and/or operating conditions not specified in this document.

**Document Control**

Revision	Date	Notes
A	7-28-2016	Initial release.
B	1-24-2025	Updated for all LDMOS design performance.

