



<u>Trailer Style Controls (5th Wheel Gen2): Operation</u> <u>Instructions</u>

Set-up #1: Programming Your Sensor

- 1. Turn panel OFF, press FRONT 10 times, then press REAR 10 times.
- 2. Follow the instructions on the screen for selecting ONE sensor using the arrows on the left side of the panel.
- 3. Place a carpenter's level on the inside of your trailer (countertop, refrigerator or floor).
- 4. Manually operate by pressing FRONT, RIGHT, LEFT & REAR buttons to get the trailer level from front to back and side to side.
- 5. Once level in both directions press ENTER. You're done.

From this point forward when you press AUTO LEVEL your trailer or vehicle will return to this position.

Set-up #2: Programming your key fob to your control panel

- 1. Turn panel off
- 2. Press LEFT 5 times, then RIGHT 5 times
- 3. Press any button on key fob, PROGRAMMED.

The key fob has an automatic shut off after 10 seconds of no use, to activate the fob simply press the BLUE button.

Gen2: Getting to know your controls...

Use the arrows to scroll through the main menu for function selection. Power shut-off switch not shown.



Key fob is for trailer applications, it only runs the front jacks and the auto-reconnect feature.

Gen2: Trailer Application, how to "un-hook" from vehicle:

Using Control Panel:

- 1. With vehicle parked & hitch disconnected, press the "POWER" button to turn system on.
- 2. Use the FRONT button to raise the front of the trailer off the vehicle.
- 3. Pull the vehicle safely away from the trailer.

Using Key fob:

- 1. Press & hold "ACTIVATE BUTTON" for 5 seconds or until panel beeps.
- 2. Press the DOWN button to extend the front 2 jacks and lift the front of your trailer.
- 3. Key fob will shut off automatically after 10 seconds.

Gen2: How to use the AUTO LEVEL feature:

- 1. Trailer: Make sure the vehicle is safely disconnected and out of the way.
- 2. Vehicle: Make sure ignition is off.
- 3. Press Power, scroll through the main menu to AUTO LEVEL, press ENTER.
- 4. Once the trailer is level, the screen will prompt SUCCESS in the window.
- 5. If "error" or "time out" (did not reach level). Do not retract, return to menu & press AUTO LEVEL again.

Gen2: How to use the MANUAL LEVELING feature:

- 1. Scroll through the main menu to MANUAL, press ENTER.
- 2. Press REAR to extend the rear 2 jacks until the vehicle/trailer moves (each button operates 2 jacks).
- 3. Raise or lower the front 2 jacks to your preference using the FRONT button.
- 4. To operate individual jacks... ^{EX.} Driver's side front leg, press FRONT & LEFT at the same time.

Gen2: Trailer Applications, how to "hook-up" to vehicle:

Using Control Panel:

- 1. Scroll to the AUTO RECONNECT feature on the menu, press ENTER. This will retract the rear jacks and extend the front jacks, lifting your trailer to the same height at which you previously disconnected from (within about 1").
- 2. Once this mode is complete, back vehicle into loading position.
- 3. Press RETRACT, then FRONT until the trailer is placed onto vehicle.

Using Key fob:

- 1. Press & hold "ACTIVATE BUTTON" for 5 seconds or until panel beeps.
- 2. Simply press the "AUTO RECONNECT BUTTON" to activate the AUTO RECONNECT feature described above.

<u>Gen2: Understanding "Lift to Connect" or "Auto Reconnect"</u> mode:

This will retract the rear jacks and extend the front jacks, lifting the trailer to the previous unloading/disconnect position within an inch. This mode can be done by the Panel (Lift to Connect) or by the single grey button above the blue button on the key fob. **This mode will not work if you have not successfully completed the Auto Level Process.** Once this mode is complete, you may back your truck under the unit and lower your front jacks. On your panel, press RETRACT then FRONT until the trailer is lowered on the vehicle safely, then until the jacks are fully retracted. On the key fob, press the "UP" arrow until the trailer is lowered on the vehicle safely, then until the jacks are fully retracted.

Automatic Leveling System Controls

Control Panel Operation...

 Make sure the key is out of the vehicle ignition.

> - If Front & Rear leds are flashing this means the house battery has reached a low voltage.



- 1. Turn panel/system on and let system run through its diagnostic mode. Lights will flash clockwise around the green foot. (System will not operate with the ignition key ON)
- 2. When the lights stop flashing, it's time to choose your function (MANUAL or AUTOMATIC). If choosing MANUAL, press and hold button until light comes on. For AUTOMATIC, simply press once and release.
- 3. When in the MANUAL mode, each leveler may be operated individually. FRONT operates right front. RIGHT operates right rear. REAR operates left rear. LEFT operates left front. When using this feature it is important to level the coach by using two levelers at a time or together. For example, right front and right rear, this puts less stress on the frame. To retract individually, press and hold the RETRACT button & the jack button. To retract all, press & hold MANUAL until light goes off, then press RETRACT.
- 4. When using the AUTOMATIC feature, simply press the AUTO button and then let the system operate itself. It is important at this time that there is NO MOVEMENT IN THE COACH. This process will take 1-3 minutes. To retract the levelers simply turn panel on and press RETRACT.

Programming the Automatic Leveling System

Turn panel/system on and let system run through its diagnostic mode. Lights will flash clockwise around the green foot.

When the lights stop flashing, push the button labeled "FRONT" 5 times. Then press the button labeled "REAR" 5 times. Once you have done this all lights on panel will begin to flash. This means you have reached in the system what is called zero mode. At this time you can operate each corner or pair of levelers individually.



FRONT indicator operates the right front.RIGHT operates the right rear.REAR operates the left rear.LEFT operates the left front.

Keep in mind the twisting/flexing of the vehicle's frame. Try to operate jacks in pairs when possible.

Once you have the coach level, you can now store a new program into the system. To do so, press the RETRACT button 3 times & wait for the green Bigfoot light to come on (will take a few seconds). If you do not want to store a new program, simply retract jacks in manual mode to avoid changing the original program (press and hold RETACT & jack button).

Platinum Leveling System Controls

Control Panel Operation...

Panel also available in black, NOTE: 1. Panel turns on when ignition turns on to inform user if jacks are up or down (alarm sounds). 2. Due to another safety feature, to operate the "START" and "RETRACT ALL" buttons, press and hold the button for 1-2 seconds then release.



Extend System:

All Up Light

- 1. Press the **Power** Button (Red LED will come on constant).
- 2. Press the **Start** Button, this brings the front of the vehicle nearly level to the rear and stabilizes the rear as well. (LED will come on until program is finished, pressing any button during operation will cancel program, Vehicle Ignition must be OFF)
- 3. Done! Vehicle is now stabilized, *if* additional adjustments are desired:
 - 1. Press Extend (now in "Extend Mode" LED will come on).
 - 2. Press & Hold the Adjustment Button for the designated corner(s) of the vehicle that is low or high. (Ex. Right or Curb side is low, press & hold RIGHT FRONT & RIGHT REAR until level, driver's side is considered the left side for reference).
- 4. **Power** Off (panel will automatically shut off after 10 minutes of no activity).

Retract System: Always visually check that all jacks are fully retracted prior to operating the vehicle.

- 1. Press the **Power** Button (Red LED will come on).
- 2. Press the **Retract All** Button until the green "All Up" light comes on constant. (This process will take up to 60 seconds. After 60 seconds the green light will flash, this means that one or more of the jacks did not fully retract, see troubleshooting)

Pressing "RETRACT" will retract all four cylinders, make sure tongue jack is set to support trailer.

Manual Leveling System Controls

Extend All: Press & hold to extend all four jacks, Retract All: Retracts all four. For individual operation: Press and release Extend Mode, press and hold



corresponding jack you want to extend. Do the same for retract function. In case of limit switch failure or "false all up light" (jack not fully retracted but it's "up" light is on)... Press Retract Mode and run that particular jack to override the limit switch, then replace switch and pin.

Wireless Leveling System Controls

STEP 1:	Press the "WAKE" button on the remote to turn receiver on.
STEP 2:	To lift the Front of the coach, press "FRONT" then "EXTEND." Hold this down until the coach moves, then release.
STEP 3:	To lift the Rear of the coach, press "REAR" then "EXTEND." Again hold this down until the coach moves, then release.
STEP 4:	To lift the Driver side of the coach, press "DRIVER" then "EXTEND." Hold until desired height is reached, then release.
STEP 5:	To lift the Passenger side of the coach, press "PASSENGER" then "EXTEND." Again, hold until desired height is reached, release.
STEP 6:	Press "WAKE" to put the system to sleep.
STEP 1:	When you are ready to leave press "WAKE" to turn on the receiver.
STEP 2:	To lower the Rear of the coach, press "REAR" then "RETRACT." Hold this down until the rear jacks are completely retracted.
STEP 3:	To lower the Front of the coach, press "FRONT" then "RETRACT." Again hold this down until the front jacks are completely retracted.

STEP 4: Press "WAKE" to put the system to sleep.

The indicator light & alarm will alert you when one of the jacks are down before you drive away. This is a standard feature on the wireless system.



Installing the Wireless Receiver

Plug the receiver pigtail into the plug attached to the central pump tank assembly. Mount the receiver using the provided TEK screws in an easy to access area without placing it in harm's way. For example, although the receiver is weatherproof, face the front component side of the receiver towards the rear of the vehicle where road debris reduce the risk of damaging the receiver.

If you are having trouble with your wireless setup (intermittent performance) the wireless connection may have some interference based on the location of the receiver (Ex. thick steel boxes) you may need to relocate your wireless receiver to another area, such as inside the coach. In order to do this you will have to order a part from Quadra Manufacturing (800-752-9815) "EZ Extension Harness - Part#: M41600"



Cylinder Installation & Assembly

Mounting the Cylinders

Pre-assemble jack prior to hanging on previously mounted weld-on bracket.

- Attach foot pad with $\frac{3}{4}$ " thin jam nut using a 1 1/16" socket.

- Remove port plugs with 3/16" allen wrench.

- Install supplied JIC elbow fittings to the bottom & top ports with 9/16" wrench.

- **DO NOT** install the extend hose to the top port on central pump systems yet, this will be done later on in installation (due to the length of hose they must go through a bleeding process).

- Place ¼" clevis pin in limit switch barrel then insert threaded limit switch with 7/8" wrench.

- For jack locations see diagrams on the following pages, but typically the front jacks should be on exposed A-frame and the rear jacks should be within 60" behind the rear axle.

- If it is a weld-on application, make sure the weld-on bracket is level and you get good penetration to the frame with full welds the entire length of the bracket. Sometimes it is easier to mount jack prior to welding by lifting assembly with floor jack, be sure to verify levelness and ground clearance. - Hang jack using at minimum of four 7/16" x 1.75" grade 8 bolts, hex nuts & lock washers. If you have 17k-lb or larger jacks (3 3/8" diameter or larger) you need a minimum of six bolts per jack. Prior to tightening, verify jack is straight & level using carpenter's level. Tighten with 5/8" wrench on bolt, 11/16" socket on nut, tighten to 70 ft.-lbs. (See Fig. 1)





NOTE: Installations may require modifications...

Certain vehicles & RV models may require modifications to the following: Weld-on brackets, Extending limit switch wires, & battery cables due to wide range of pump locations. Re-routing generator exhaust, RV plumbing or wiring, Modification to sub-floor brackets or joists, Storage boxes & Floors. Hydraulic lines in kit are universal/generic and may not fit every application, you can call Quadra and order any length hose you need separately.

Make sure the proper hardware is used in the proper locations. Everything should be attached and level prior to tightening. All hardware to be fastened to following torque specs:

1/2" (5 ½" & 9" Bolts) = Torqued to 80 ft/lbs.
7/16" (1 ½" Bolts) = Torqued to 70 ft/lbs.
3/8" (U-Bolts) = Torqued to 45 ft/lbs.
3/4" (Nuts for Foot Pads) = Impact must be used and one to two threads should be visible past nut.

Vertical Tank Assembly for *Central Pump* Systems

Tank Assembly will be pre-assembled & pre-wired direct from factory.

- Mount the pump using a minimum of two 7/16" bolts, nuts & lock washers.

- Plumbing is shown in Fig. 2 below, use 9/16" wrench and be careful not to under or over-tighten the hydraulic fittings. Sometimes marking the hydraulic lines with tape may make it easier.

- **DO NOT** install the top extend lines to the jacks themselves yet, this will be done later in installation.

- The main wire harness will plug directly into the 14-pin connecter that is pre-wired to the assembly.

- Route the ground harness (attached to ground shown below) to a grounded surface on the vehicle frame.

- Finally installing the plastic three sided tank cover, this should be done later on in the assembly.

- The tank cover will need to be trimmed to your liking around the hydraulic lines. Fasten the tank cover with at least two self-threading screws, be careful not to puncture the plastic reservoir.



Central tank assembly is typically located near the "center" of the unit, Example: In front of rear axle on driver's side frame rail (outside of rail or between rails).



Mounting Tank Assemblies (Quad or Central)

Our tank assemblies are weather resistant and must be mounted vertically and can be mounted externally on the vehicle's frame by drilling holes in the frame or welding a bracket, tanks can be mounted to a cylinder bracket or inside a storage box. Use at minimum two 7/16" or 3/8" bolts per tank assembly. Take care when mounting and running hydraulic lines & wiring to avoid moving parts, exhaust, etc.

Grounding your tank assembly...

Each pump requires 12V power and sometimes an additional ground is required for the pump/motor to operate correctly. This is true for central pump, quad pump and 2pt systems. An auxiliary ground harness (optional) could come pre-wired to the tank assembly, otherwise attach a 10 gauge wire (4 gauge for horizontal pump) from the location shown below (solenoid mounting stud from each solenoid) and to a good grounded surface on the trailer frame or directly to the negative terminal on the battery. Quad pump assembly shown below, but the same solenoids are used on the vertical central pump assembly.



Main Wire Harness – Automatic Leveling & Platinum System

Installing the 14-Pin Wiring Harness Central Pump Automatic Leveling & Platinum Systems

The harness has two ends with plugs; the "panel" end has a 14-pin connector & a 6-pin. This end will need to route to the control panel's location (typically near entry door). The other end will have one 14-pin connector that will plug directly into the tank assembly. The rest of the harness has two wires: Black & Tan, both of these wires plug directly into the Limit Switch that you installed previously onto each jack. Attach the wire harness to the frame rail (usually inside of rail with other wiring) with p-clips or zip ties safely routing away from any moving suspension parts or exhaust (complying with RVIA regulations). Example diagram on next page...

Installing the 14-Pin Wiring Harness Quad Pump Automatic System

The main wire harness will have three wires for each corner: One wire goes to the limit switch (has spade connector) (the limit switch has two wires coming from it, the wire with the eyelet goes to ground, the spade connects to harness). The other two wires (same color except one has a tracer) have female push-on connectors that plug into the operation posts on each solenoid. The battery harness has eyelets at each corner that attaches to the power stud on the lower solenoid (with the copper strip). *See the "Medium Tank Assembly" diagram earlier in the booklet.* The main harness lead has a 14-pin connector at the end, this end will need to route to the sensor location. Attach the wire harness to the frame rail (usually inside of driver's side rail with other wiring) with p-clips or zip ties safely routing away from any moving suspension parts or exhaust (complying RVIA regulations). Example diagram on next page...

Installing the Limit Switches to the Jacks



GROUND

IGNITION HOT



Installing the Central Pump Automatic Leveling Sensor & Control Panel: Fasten the sensor to a secure structure (usually the floor) inside the vehicle (not weatherproof) ensure that it is mounted level and the arrow on top of the sensor is facing the correct way. Plug the 14-pin & 6pin from the harnesses into the back side. The 6-pin connector only has needs the yellow wire to be hooked up for central pump systems. The yellow wire needs to tie into an ignition or accessory hot wire from the vehicle. For quad pump systems, the red wire goes to fused 12V and black wire to ground. After doing so attach the interface harness (8-pin connector) to the front of the sensor and attach to the Control Panel. The panel is typically mounted near the side entry door, on a cabinet wall or panel somewhere inside the coach, or inside Quadra's optional plastic box assembly with the harness loosely

coiled behind the driver's seat.

Installing the Platinum Control Panel

Plug the 14-pin & 6-pin from the harness into the back side. There is a yellow wire coming from the 6-pin that needs to tie into an ignition hot wire from the vehicle. The panel may be mounted on the dash in a safe location or on a panel somewhere on inside the coach, or inside Quadra's plastic box assembly with the harness loosely coiled underneath the driver's seat. **Optional safety feature for Platinum panels with grey overlay or version A on back**, features an in-line toggle switch to shut power off to the panel to prevent operation while driving down the road from children, etc. Find the red wire from the 6-pin harness that goes to the back of the panel. Cut and splice the included wires to route to the toggle switch that should be located near the Platinum panel for convenience.

Battery Cable Installation for Central Pump & 2pt Systems

Supplied will be a 4 gauge battery cable that needs to be cut into two pieces.

- The 1st to run from the Solenoid power stud (marked BATT+) to the 80 amp breaker AUX stud.

- The 2nd to run from the BAT stud on the breaker to the Positive Terminal on the coach's house battery. Hooking up the power should be the final wiring step so make sure this is done after all the other electrical work is done for safety. The supplied 80 amp breaker should be securely fastened in the battery box. Ground cable (attached to central pump assembly, typically white 10ga. wire should be fastened to vehicle frame or extended to negative terminal on battery.

Installing the Wireless Receiver

Mount the Wireless Receiver near the tank assembly, check and plug the wiring connector from the receiver to The tank assembly to make sure it reaches, the Receiver is weatherproof but be aware of possible road debris, clear of exhaust and other moving parts.

Example below of routing the Quad Pump Automatic & Manual systems 14-pin wire harness. Diagram represents a vehicle, but principles are the same for trailers. The Central Pump Automatic & Platinum systems harness is similar except that the leads to each corner or jack have only a tan & black wire that plugs into the limit switch and the end of the harness with the 14-pin connector plugs into the pump while the end with the



MAIN WIRE HARNESS DIAGRAM

14-pin & 6-pin connectors plug into the Automatic's Sensor or Platinum panel. Take care to avoid high heat areas and moving parts.

Installing the Quad Pump **Automatic Leveling Sensor** & Control Panel: Fasten the sensor to a secure structure (usually the floor) inside the RV (control is not weatherproof) ensure that it is mounted level and the arrow on top of the sensor is facing the correct way. Plug the 14-pin & 6-pin from the harnesses into the back side. The 6-pin connector only has three wires: red, yellow and black. The yellow wire is for ignition or accessory hot wire from a vehicle and will not be required to install on a trailer. The red wire needs to attach to a fused 12V power source (7.5 amp fuse). The black wire is ground. After doing so attach the interface harness (8-pin connector) to the front of the sensor and attach to the Control Panel. The panel is typically mounted near the entry door on a vertical cabinet wall with access behind it.

Installing the Platinum Control Panel

Plug the 14-pin & 6-pin from the harness into the back side. There is a yellow wire coming from the 6-pin that needs to tie into an ignition hot wire from the vehicle. The panel may be mounted on the dash in a safe location or on a panel somewhere on inside the coach, or inside Quadra's plastic box assembly with the harness loosely coiled underneath the driver's seat. **Optional safety feature for Platinum panels**, features an in-line toggle switch to shut power off to the panel to prevent operation while driving down the road from children, etc. Find the red wire from the 6-pin harness that goes to the back of the panel. Cut and splice the included wires to route to the toggle switch that should be located near the Platinum panel for convenience.

Battery Cable Installation for <u>Central Pump</u> Systems

Supplied will be a 4 gauge battery cable that needs to be cut into two pieces.

- The 1st to run from the Solenoid power stud (marked BATT+) to the 80 amp breaker AUX stud.

- The 2nd to run from the BAT stud on the breaker to the Positive Terminal on the coach's house battery. Hooking up the power should be the final wiring step so make sure this is done after all the other electrical work is done for safety. The supplied 80 amp breaker should be securely fastened in the battery box.

Battery Harness Installation for <u>Quad Pump</u> Systems

Supplied will be a 4 gauge battery harness that must be ran from the coach's house battery to all four pump assemblies at the solenoid power stud (with the copper strip). For the end going to the breaker read below: - Mount the 120 amp breaker near the battery (usually in the battery box) cut a piece of the battery harness off that is long enough to reach the battery from the breaker.

-Install the eyelet to the now open end of the battery harness and hook it to the BATT post on the breaker. -Install the eyelet to the short cut piece and hook that to the AUX post on the breaker and to the positive terminal on the coach's house battery. Hooking up the power should be the final wiring step so make sure this is done after all the other electrical work is done for safety.

Installing the Manual Control Panel: Plug the 14-pin harness & 6-pin into back of panel, mount with bezel.

Installing the Wireless Receiver

Mount the Wireless Receiver near the tank assembly, check and plug the wiring connector from the receiver to The tank assembly to make sure it reaches, the Receiver is weatherproof but be aware of possible road debris, clear of exhaust and other moving parts.

Central Pump Final Extend Hose Installation & Bleeding the System

During installation of the hydraulic lines, air is internally captured in the hose. Due to this, bleeding the air out of the system is necessary for the system to work properly. This process is done at the end of installation and requires two people and can be messy, so as a warning make sure you are wearing eye protection and have rags ready to use. Make sure all hose fittings are tight on the pump side and the retract side of the jacks. Extend hose fittings should still be un-installed.

- With person #1 running the panel, go into Manual Mode, all jacks should be fully retracted.

- Person #2 (armed with a 5/8" OR 9/16" wrench, safety glasses, rag and a one gallon container) needs to access the left rear jack and place the un-attached extend hose into the empty container.

- Now person #1 will extend that left rear jack from the panel (press & hold button).

- Fluid & air will be spilling out of the port, once a solid stream of fluid occurs, person #1 will release the button on the panel, after fluid stops flowing person #2 should install the hose fitting to the jack.

- Repeat these steps with the rest of the jacks.

- After doing so, extend all jacks fully and let stand for 15 minutes.

- Then retract all the jacks and remove the tank cover and check your fluid level to verify the fluid in the reservoir is around $1 \frac{3}{4}$ " below the top (ATF Dexron III) do not fill to the top!

Finally install the tank cover, check that all hardware is tight, the sensor is facing the correct way and is mounted level and the house battery is fully charged.

In some instances, the front jacks may need to be dis-mounted from underneath the cab to access the top extend ports during the bleeding procedure.

Bleeding Quad Pump systems

In Manual mode, extend all four jacks to complete extension and leave in this position for 20 to 30 minutes. This pushes all the air out of the lines by weight pressure. After turn panel back on and press Retract.

Troubleshooting - Hydraulic Cylinder/Plumbing Related

What fluid do we use in the system? Automatic Transmission Fluid Dexron III ATF Cylinders running "choppy"... Bleed the system, if central pump system, try quad pump method first. Cylinders make loud "squeaking" noise while operating... Spray rams with Teflon spray (dry lubricant). Hydraulic fluid on footpad or on ground around cylinder... Loose fitting or broken hydraulic line. Cylinders "creep" down or don't hold pressure when lifting/holding coach...

- Check fluid level, Check for leaks in hydraulic lines/fittings
- Possibly plumbed backwards... (Bottom port on cylinder tube connects to right port on pump, etc.)
- Relief Valves have failed on pump motor... replace motor/tank assembly
- Hydraulic seal failure, check for oil around bottom of cylinder or welds... replace cylinder

Auto Leveling/Platinum Control: If the "All Up" light is not coming on and you hear the **buzzing sound from your panel when the vehicle ignition is on** it might be a limit switch on one of the jacks. After attempting to retract all four jacks from the panel and doing a visual check to verify that the jacks are indeed retracted but the panel has no "All Up" light. The first step is to extend each jack a few inches and individually retract one at a time. Sometimes the foot pad retracts crooked and doesn't fully engage the pin. If that doesn't work, with the jacks fully retracted, press the RETRACT button on the panel and manually pull each limit switch pin up to see if that engages the switch, if the panel shuts the pump off then that limit switch is not engaging properly. To fix this, it could be the foot pad is loose, remove & re-tighten the ¾" nut with a 1 1/16" socket with an impact wrench. If this does not work you can get a "vacuum cap" at your local hardware store for the ¼" diameter pin which extends the length of the pin and completes the circuit.

If you have an "All Up" light but your jacks are NOT fully retracted, we call this a false all up light, this means you have a bad limit switch (they can stick in the "passing" position due to build-up of road debris or rust).

To get you out of a jam or to bypass this... Central pump systems: disconnect the wires to the limit switch, and plug the two wires from the harness that usually go to the limit switch and plug them into each other (black & tan wires) this closes the circuit and allows the jack to be retracted. Quad pump systems: connect the colored wire from the main harness and connect it to the ground wire from the limit switch (or to frame).

Troubleshooting - Continued...

(Auto Leveling) If the **LEFT** & **RIGHT** lights are flashing that means the program "timed out", which may mean the coach is on too un-level ground or there was too much movement in the coach during the automatic leveling program. Try again.

If rear jacks are hanging too low to the ground with the jacks retracted fully, check underneath the coach and check to see if the jack can slide up one row of holes. If this can be done, make sure you raise both rear jacks the same height and tighten each mounting bolt to 70 ft/lbs. If your coach is equipped with an airbag system, just increase air pressure slightly to raise the coach.

If a single jack on a central pump system is simply not working properly, the **valve or coil** to that particular jack might be bad. To replace, simply call or go online to order part number **#M35008**.

Panel won't turn on, system won't run, clicking noise, FRONT & REAR lights flash...

Battery low, panel won't turn on = coach battery, the system relies on the house battery. The battery needs to be nearly 100% charged for the system to work, it doesn't make a difference if the coach is new, that doesn't mean the battery is fully charged or even good. Battery's don't charge instantaneously, so one can't just expect to hook it up to a charger and the system will work immediately, if the battery is good, then the unit might have a ground issue. Auto systems must un-plug/re-plug the interface cable to clear code on panel regardless.

Panel is on, but pump(s) are not working OR solenoids clicking but pump/motor is not running... Auxiliary Ground Cable

Sometimes required for heavily coated frames, solenoids need a 10 gauge wire to be attached to one mounting stud for both solenoids on each pump assembly (central or quad) that isn't working properly to the vehicle's frame for optimum performance.

Rocker Switch Controls

Included is a harness (#M43800) that routes from the tank assembly to the rocker control switch. The red wire is the 12V power, this goes from the power stud on the tank assembly (on copper strip with 5/16" studs from solenoids) to the center post on the switch. The black wire is ground & is not needed for this switch. The grey wire goes from the retract operation post on the retract solenoid to the post labeled "1" on the switch. The blue wire goes from the extend post on the extend solenoid to the post labeled "3" on the switch. The switch is not waterproof & must be installed inside the coach.



0



VERSION #1: (SHOWN) THE "TEE" FITTINGS MOUNTED TO THE DRIVE JACK.

2x

VERSION #2: INCLUDES MOUNTING THE "TEE" FITTINGS TO THE PUMP FITTINGS.

VERSION #3: RUNNING TWO LINES FROM THE PUMP AND PLACING THE "TEE" FITTINGS IN-LINE, THEN RUNNING INDIVIDUAL LINES TO EACH JACK FROM THE "TEE" FITTINGS.

Warranty Guide – Owner must active warranty (call/online)

OEM Installed Auto Leveling Systems: 1 year parts, 1 year labor. Wireless Central Pump Systems: 1 year parts, 1 year labor. Platinum Central Pump Systems: Lifetime Cyliners, 2 years parts, 1 year labor. Automatic Leveling Systems: Lifetime Cylinders, 2 years parts, 1 year labor. Manual Leveling Quad Pump Systems: Lifetime Cylinders, 2 years parts, 1 year labor. 1pt & 2pt Round Leg Stabilizing Systems: 1 year parts, 1 year labor. Square Leg Landing Gear Systems: 5 years cylinders, 2 years parts, 1 year labor.

Should the product be defective due to workmanship and/or material flaws, we will repair/replace the defective material. **Core charges may be applied and refunded on certain components.**

Quadra is NOT responsible for:

> Freight on warranty parts.

- Replacing footpads, bolts, or fluids lost as a result of failure to maintain the system (Loose footpads should be tightened at owner's expense).
- Damages caused by abuse, misuse, negligence, misapplication, error of operation, accidental or purposeful damage or faulty installation, including but not limited to hoses, fittings & wiring components.
- Liability for loss to the vehicle, or apparatus or property, loss of time, manufacturing costs, labor, material, loss of profits, consequential damages (direct or indirect).
- For transportation to and from a service center, onsite service calls to or from the customer, damage from road hazard, loss of salaries, commissions, lodging, towing charges, bus fares, car rentals, fuel expense, telephone charges, inconvenience compensation while repairing or replacing a defective part or material.

This warranty voids all previous issues. Effective date: January 1st 2022

OWNERSHIP MUST BE REGISTERED WITHIN 30 DAYS FROM THE DATE OF PURCHASE TO ACTIVATE WARRANTY. Do it online at BIGFOOTLEVELER.com!

Prior to any work being done an <u>authorization number must be obtained</u> by calling 269-483-9633 for Warranty Parts or Service Labor. For full warranty transcript just contact us!

Service labor based on a flat rate schedule determined by Quadra for <u>authorized</u> work performed will be reimbursed. This will eliminate much diagnostic time and avoid <u>refusal of</u> <u>unauthorized claims.</u> Many problems may be resolved by contacting a Quadra service representative.

Provide the system serial number here

Emergency Service

•

For afterhours emergency service please call our normal office number **800-752-9815** and follow the instructions.