

## Hyosung: Enter Customer Setup ▶ Select Processor ▶ TCP/IP Type

Nautilus Hyosung:	
Cardtronics:	Visa Framed
Columbus Data:	Visa Framed EMV; Standard
MoneyTree(DNS):	Standard
EFX:	Standard
Elan/Genpass:	Visa Framed
1 <sup>st</sup> ISO	Standard / visa
Metavante:	Standard
Switch Commerce:	Visa Framed
Worldpay/RBS Lynk:	Standard
Universal Money	Standard

\*\*\*\*\*SSL MUST BE DISABLED\* \*\*\* \*SSL MUST BE DISABLED\*\*\*\*\*

## GenMega: Enter Customer Set Up ▶ Change Processor ▶ Communication

Hantle/Tranax/Genmega:	
Cardtronics:	Visa Framed TCP/IP
Columbus Data:	Standard TCP/IP
Money Tree(DNS):	Visa Framed TCP/IP
EFX:	Standard TCP/IP
Elan/Genpass:	Visa Framed TCP/IP
1 <sup>st</sup> ISO	SSL LENGTH PREFIX W/O EFX
Metavante:	Standard TCP/IP
Switch Commerce:	Visa Framed TCP/IP
Worldpay/RBS Lynk:	Standard TCP/IP
Universal Money	Standard TCP/IP*
Triton:	
All Processors: 8: TCP/IP 9: TDL TCP/IP No CRC	

- If Status Light is not a steady flashing green light, please call for further trouble shooting assistance.
- If Ethernet port is not showing gold light when Cat5 cable is plugged in, verify connection to ATM's modem board. Also, make sure a good Cat5 cable is being used.
- If no cell on light and/or signal bars are lighting up after box has received steady power flow for 2-10 minutes, attempt to power cycle. If problem persists, please call for further assistance.
- When cell on light and signal bars are glowing solid green and communication errors occur, attempt to power cycle the ATM and perform basic trouble shooting.
- If the Signal Light is flashing, this could indicate a software update is downloading.
- If this is the case wait until unit reboots by itself. If the Signal Light does not stop flashing after 5 minutes then call.
- If using Triton on dial-up, set the baud rate to 1200

## Programming Guide

- For TCP/IP via Cat5 Cable:

- ◆ Log in with Master Password and Select Host Setup.
- ◆ Select Host Address, Disable URL and Use this for Address 1 and 2:

192.168.1.90

**\*\*Enter the port for your ATM's processor as shown below!\*\***

- ◆ Exit back to the Main Menu ◆ Enter System Setup

For Hyosung: Enter Terminal IP.

For GenMega Enter Device Set Up, and then ATM TCP/IP Set up.

- ◆ Select Static IP (Genmega) / Disable DHCP (Hyosung) and enter:

Terminal IP Address: 192.168.1.91 ~ RMS = 192.168.1.100

Subnet Mask: 255.255.255.0

Gateway: 192.168.1.90

For Genmega machines, make sure to select **APPLY** to save!

For **ATM's on Dial-Up**, simply enter numbers below in **Host Setup**:

Processor	Phone #1	Phone #2	Port 1&2 for TCP/IP
1st Iso	18779991309	18005304784	8444
Columbus Data	18664334608	18669233608	7000
Cardtronics	18664036747	18664036745	7004
EFX	18558711292	18666496124	446
ELAN	18004726210	2222	7002
World Pay / RBS	18008275965	18004865965	6661
Metavante	18008837723	18669564590	450 36 /
Money Tree	18008165409	18008165410	6666
Switch Commerce	18009318497	18009316030	7003
Universal Money	18003480574	18003480574	4443 or 453

### NOTE:

- Other settings that may affect communication need to be verified with your ATM Processor. These include, but are not limited to:
- Message Format settings / Standard 1 or 3 Options
  - The Status of the Master Key • Terminal ID Accurately Entered