

Materials Testing Laboratory

Materials Technology Division

Tel: 2788 5538 2788 5541

Fax: 2788 5522

5th Floor, HKPC Building, 78 Tat Chee Avenue, Kowloon Tong, Hong Kong

材料科技部

電話: 2788 5538 2788 5541 傅真: 2788 5522

香港九龍塘達之路78號生產力大樓5樓

Job Number:

1009C001

Date: 29-10-10

Page 1 of 2

Sample Description:

Pipe

Sample Source:

The H.K. & China Gas Co Ltd

14/F., 363 Java Road, North Point, Hong Kong

Sampling Done by:

The above company

Receipt Date:

04-10-10

Test Performing Date:

06-10-10 to 27-10-10

Copper-Accelerated Acetic Acid-Salt Spray (Fog) Test for Corrosion

Nature of Test:

Resistance, as specified by ASTM B368-09

Test Results:

Copper-Accelerated Acetic Acid-Salt Spray (Fog) Test was performed in accordance with conditions laid down in ASTM B368-09 as follows:-

Sodium Chloride (Solution) 5%

Copper Chloride (CuCl₂•2H₂O) 0.25 ± 0.02 g/L

pH adjusted to 3.1 by addition of Acetic Acid

Chamber Temperature $50 \pm 2^{\circ}$ C Saturation Tank Temperature $65 \pm 2^{\circ}$ C Air pressure 0.12 MPa

| Sample Code | Sample Description | | | | | | | |
|----------------|---|--|--|--|--|--|--|--|
| 9 | G.I. pipe pre-coated with Epoxy Primer | | | | | | | |
| 10 | G.I. pipe with Class 4 corrosion | | | | | | | |
| 11 | G.I. pipe with Class 5 corrosion | | | | | | | |
| 12 | G.I. pipe with Class 3 corrosion & touch up with Rust bullet | | | | | | | |
| | (after 500hrs. Neutral Salt Spray) | | | | | | | |
| 13 | G.I. pipe with Class 4 corrosion & touch up with Rust bullet | | | | | | | |
| | (after 500hrs. Neutral Salt Spray) | | | | | | | |
| 14 | G.I. pipe with Class 3 corrosion & touch up with Rust converter & top paint | | | | | | | |
| 15 | G.I. pipe with Class 4 corrosion & touch up with Rust converter & top paint | | | | | | | |
| 16 | G.I. pipe with Class 4 corrosion, half touch up with Epoxy primer & half with | | | | | | | |
| 16 | zin rich primer | | | | | | | |

.../2



Materials Testing Laboratory

Materials Technology Division

Tel: 2788 5538 2788 5541

Fax: 2788 5522

5th Floor, HKPC Building, 78 Tat Chee Avenue, Kowloon Tong, Hong Kong.

電話:2788 5538 2788 5541 傅真:2788 5522

香港九龍塘陸之路78號生產方大樓5樓

1009C001

29-10-10

Date : 29-10-Page 2_{of} 2

Job Number:

Pipe

Sample Description:

The H.K. & China Gas Co Ltd

Sample Source:

14/F., 363 Java Road, North Point, Hong Kong

Sampling Done by:

The above company

Receipt Date:

04-10-10

Test Performing Date:

06-10-10 to 27-10-10

Copper-Accelerated Acetic Acid-Salt Spray (Fog) Test for Corrosion

Nature of Test:

Resistance, as specified by ASTM B368-09

Test Results:

| G 1 | Result | | | | | | | | | | | |
|--------|--------|--------------|-------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--|
| Sample | 24 | <u>72</u> | 120 | 168 | 216 | 264 | <u>312</u> | <u>360</u> | 408 | <u>456</u> | <u>500</u> | |
| Code | hours | <u>hours</u> | hours | <u>hours</u> | |
| 9 | N | N | R | NF | NF | R | NF | R | В | NF | В | |
| 10 | R, W | R | NF | NF | NF | NF | NF | R | NF | R | R | |
| 11 | N | N | N | N | N | N | R | NF | R | NF | NF | |
| 12 | R | NF | R | NF | |
| 13 | N | N | R | R | NF | NF | В | В | В | В | NF | |
| 14 | R | R | R | R | P | NF | В | В | B, R | В | NF | |
| 15 | R | R | R | R | P | R | В | В | NF | NF | NF | |
| 16 | R, W | R | R | NF | NF | R | R | R | R | NF | R | |

R= Rusting was observed

N = No observable change

NF = No further observable change

W = White corrosion spots were observed

P = Peeling off of coating was observed

B = Blistering was observed

Dr. Kinny L.K. Yeung

B.Sc. M.Sc. Ph.D. C.Chem MRSC FIMF. F.I.Ceram FIM

General Manager - Materials Technology Division




Annex of 1009C001



Sample Before Testing (Sample 9)



Sample Before Testing (Sample 10)



Sample Before Testing (Sample 11)



Sample Before Testing (Sample 12)



Sample Before Testing (Sample 13)



Sample Before Testing (Sample 14)





Sample Before Testing (Sample 15)



Sample Before Testing (Sample 16)



Sample After Testing - 24 hours (Sample 9)



Sample After Testing - 24 hours (Sample 10)



Sample After Testing - 24 hours (Sample 11)




Sample After Testing - 24 hours (Sample 12)





Sample After Testing - 24 hours (Sample 13)



Sample After Testing - 24 hours (Sample 14)



Sample After Testing – 24 hours (Sample 15)



Sample After Testing - 24 hours (Sample 16)




Sample After Testing - 72 hours (Sample 9)



Sample After Testing - 72 hours (Sample 10)





Sample After Testing - 72 hours (Sample 11)




Sample After Testing - 72 hours (Sample 12)



Sample After Testing - 72 hours (Sample 13)



Sample After Testing - 72 hours (Sample 14)




Sample After Testing - 72 hours (Sample 15)




Sample After Testing - 72 hours (Sample 16)







Sample After Testing - 120 hours (Sample 9)




Sample After Testing - 120 hours (Sample 10)




Sample After Testing - 120 hours (Sample 11)



Sample After Testing - 120 hours (Sample 12)




Sample After Testing – 120 hours (Sample 13)



Sample After Testing - 120 hours (Sample 14)







Sample After Testing - 120 hours (Sample 15)




Sample After Testing - 120 hours (Sample 16-1)



Sample After Testing - 120 hours (Sample 16-2)



Sample After Testing - 168 hours (Sample 9)




Sample After Testing - 168 hours (Sample 10)




Sample After Testing - 168 hours (Sample 11)







Sample After Testing - 168 hours (Sample 12)



Sample After Testing - 168 hours (Sample 13)




Sample After Testing -168 hours (Sample 14)



Sample After Testing -168 hours (Sample 15)




Sample After Testing -168 hours (Sample 16-1)



Sample After Testing - 168 hours (Sample 16-2)






Sample After Testing - 216 hours (Sample 9)




Sample After Testing - 216 hours (Sample 10)




Sample After Testing - 216 hours (Sample 11)



Sample After Testing - 216 hours (Sample 12)




Sample After Testing – 216 hours (Sample 13)



Sample After Testing - 216 hours (Sample 14)







Sample After Testing - 216 hours (Sample 15)



Sample After Testing - 216 hours (Sample 16)




Sample After Testing - 264 hours (Sample 9)



Sample After Testing - 264 hours (Sample 10)



Sample After Testing – 264 hours (Sample 11)




Sample After Testing - 264 hours (Sample 12)






Sample After Testing - 264 hours (Sample 13)



Sample After Testing - 264 hours (Sample 14)




Sample After Testing – 264 hours (Sample 15)



Sample After Testing - 264 hours (Sample 16-1)



Sample After Testing – 264 hours (Sample 16-2)




Sample After Testing - 312 hours (Sample 9)






Sample After Testing - 312 hours (Sample 10)




Sample After Testing - 312 hours (Sample 11)




Sample After Testing - 312 hours (Sample 12)



Sample After Testing - 312 hours (Sample 13)




Sample After Testing - 312 hours (Sample 14)




Sample After Testing - 312 hours (Sample 15)






Sample After Testing - 312 hours (Sample 16-1)




Sample After Testing - 312 hours (Sample 16-2)



Sample After Testing - 360 hours (Sample 9)



Sample After Testing - 360 hours (Sample 10)



Sample After Testing - 360 hours (Sample 11)




Sample After Testing - 360 hours (Sample 12)






Sample After Testing - 360 hours (Sample 13)




Sample After Testing - 360 hours (Sample 14)




Sample After Testing - 360 hours (Sample 15)



Sample After Testing - 360 hours (Sample 16-1)



Sample After Testing - 360 hours (Sample 16-2)



Sample After Testing - 408 hours (Sample 9)






Sample After Testing - 408 hours (Sample 10)




Sample After Testing - 408 hours (Sample 11)



Sample After Testing - 408 hours (Sample 12)



Sample After Testing - 408 hours (Sample 13)




Sample After Testing - 408 hours (Sample 14)



Sample After Testing - 408 hours (Sample 15)






Sample After Testing – 408 hours (Sample 16-1)




Sample After Testing - 408 hours (Sample 16-2)



Sample After Testing - 456 hours (Sample 9)



Sample After Testing - 456 hours (Sample 10)



Sample After Testing - 456 hours (Sample 11)




Sample After Testing - 456 hours (Sample 12)





Sample After Testing - 456 hours (Sample 13)




Sample After Testing - 456 hours (Sample 14)



Sample After Testing - 456 hours (Sample 15)



Sample After Testing - 456 hours (Sample 16)



Sample After Testing - 500 hours (Sample 9)



Sample After Testing - 500 hours (Sample 10)






Sample After Testing - 500 hours (Sample 11)



Sample After Testing - 500 hours (Sample 12)



Sample After Testing – 500 hours (Sample 13)



Sample After Testing - 500 hours (Sample 14)



Sample After Testing - 500 hours (Sample 15)



Sample After Testing – 500 hours (Sample 16)