

Every other week, it is important to preform a more detailed cleaning.

Bi-Weekly Maintenance

1. Remove any remaining product from cylinders
(If there is still product remaining in the bag, place it in the rear storage compartment of the machine)
2. Remove the cylinders from the machine (disconnect the wires)
3. Remove the domes and wiper rings.
4. Clean bottom tray with spray cleaner (Stera-Sheen) and warm towel
5. Wipe down inside door panel and door jam with warm moistened towel and mild detergent
6. Take domes, wiper rings and lids and wash in the sink with sanitizer and after rinsing leave to air dry.
7. Wipe cylinders out with a dry cloth.
8. Lubricate cylinders generously with spray lubricant.
9. Reassemble cylinders with wiper rings, dome's and lids.
10. Using the tube lube, lubricate the bottom plug of each cylinder
11. Place cylinders back in the machine wires reattached.
12. Reload machine with product and clean spigot assemblies.

Total Time: 30 Minutes