

GENERAL INFORMATION

GPR-1 is specifically formulated to quickly and effectively graffiti from surfaces previously protected with GRAFFITI-PRUF™ sacrificial barrier. It is safe, easy to use and will not harm the environment.

GPR-1 is intended to be used in areas where pressurized hot water sprayers cannot be used or are impractical.

GPR-1 is easily applied with trigger sprayer, sponge or brush. The product is most effective on smooth or medium textured surfaces.

GPR-1 can be used to remove large areas of graffiti where hot water is not available.

GPR-1 is non-flammable, non-toxic and biodegradable. It is available in bulk or safe aerosol packages. It complies with all known FDA and CARB standards.

GRAFFITI SYSTEM

GRAFFITI-PRUF™ and GPR-1 are designed to be used together as a graffiti protection system for walls, restroom partitions, building exteriors and interiors, utility boxes, school lockers, public phones, highway barriers and signs, bridges and all surfaces that may be subject to graffiti vandalism.

WARNING

- KEEP OUT OF THE REACH OF CHILDREN
- DO NOT TAKE INTERNALLY
- AVOID CONTACT WITH EYES

DIRECTIONS FOR USE

Shake well before using. Apply to coated areas that have been vandalized using a sponge, sprayer, brush or roller.

SPONGE – For smaller, smooth surfaces.

SPRAYER – All rough or textured surfaces such as masonry.

BRUSH or ROLLER – Smooth surfaces such as signs and metals.

- (A) Allow to work for 1 to 3 minutes. Use a bristle brush on textured surfaces to most effectively lift the graffiti from the surface. Use a soft brush on smooth surfaces. Repeat on suborn areas.

- (B) Use a pressure washer and rinse thoroughly with water. Hot water pressure washer will expedite removal.

- (C) Allow to air dry.

- (D) Apply GRAFFITI-PRUF™ or PRMAKOTE® graffiti barriers to protect the surface from future, permanent marring.

CAUTION

- Use with adequate ventilation
- Do not swallow.
- Avoid contact with eyes.
- Avoid prolonged or repeated contact with skin
- Wash thoroughly after handling.

FIRST AID

INHALATION: Move to fresh air. Consult physician immediately if breathing is difficult and give artificial respiration.

EYE CONTACT: Flush with water for 15 minutes and get medical care. Remove contact lenses, if worn.

SKIN CONTACT: Wash skin with soap and water. Remove contaminated clothing.

INGESTION: Drink large amounts of water. DO NOT INDUCE VOMITING. If vomiting occurs, give lots of water. Keep head below hips to prevent aspiration of liquid into lungs. Seek medical attention immediately.

FIRE / SPILL / LEAK

SPILL/LEAK: Recover and reclaim larger quantities. Collect smaller quantities with suitable absorbent and place in sealed container for disposal.

STORAGE

GPR-1 must not be allowed to freeze. Any material that freezes must be discarded. Containers must be kept closed to prevent evaporation of the water in the material. The material will withstand temperatures up to 140°F, but care should be taken to avoid prolonged exposure to direct sunlight. GPR-1 may be stored for up to 60 months without excessive deterioration.