

BREEZAIRE PRODUCTS COMPANY

8610 Production Avenue San Diego, California 92121

Phone (858) 566-7465 Fax (858) 566-1943

Web Site: www.breezaire.com Email: info@breezaire.com

REPLACING SENTRY III CONTROL PANEL

***COOLING UNIT MUST BE DISCONNECTED**

FROM POWER SOURCES

1. Using a Phillips screw driver, remove the two (2) screws holding the control panel to the base.
2. Pull the control unit forward removing it from the base.
3. Label each wire with tape (white medical). Position your replacement control panel near the original one so that you may start to transfer the wires.
4. Use Needle Nose pliers to remove each connector, one by one from the original control board and move it to the replacement control board.
5. Before applying power to the cooling unit insert the control panel back in the base of the unit and replace the screws in the panel.
6. Connect cooling unit to the power outlet.

(NOTE - This control board is similar to a small home computer and can be effected by unstable power. Power surges and/or electrical storms can cause this control board to malfunction or lose its memory settings. Connecting it to a surge protection device can help protect your control board against various power stability problems.)



QR Scan for youtube link