

# Parts List (Continued)


PARTS LIST				
PART NUMBER	DESCRIPTION	QTY		
AS-40001	Wall Bracket	2		
AS-40002	Cross Brace	2		
AS-40003	Lower Bracket Knee Brace	1		
AS-40005	Inside Post	2		
AS-40006	Outside Post	2		
AS-40007	Inside Siderail	2		
AS-40008	Outside Siderail	2		
ES-8011	Higher Bracket Knee Brace	1		
AS00030	30" x 11" Step Assembly	6		
3/8-16x1SFB	3/8"-16 x 1" Flange Bolt	70		
3/8-16SFN	3/8"-16 Whiz Lock Nut	70		
5/16-18x3/4FB	5/16"-18 x 13/4" Flange Bolt	6		
5/16-18SFN	5/16"-18 Whiz Lock Nut	6		
Floor Screw	Self-tapping screw	10		
HRC1500	1.5" Handrail Clamp	6		
TR1504810	1.5" Swaged Handrail/Guardrail	3		
TR1004810	1.0" Swaged Indermediate Rail	2		

\*Includes one (1) AWT4401 and one (1) AWT4402

- A. To build the lower wall bracket (AWT4401), place the cross brace perpendicular to the wall bracket, lining up with the middle set of four holes, as shown in Figure 1.
- B. Secure in place with four (4) 3/8" Flange Bolts and four (4) 3/8" Lock Nuts.
- C. Place the diagonal brace on the wall bracket and cross brace.
- D. Secure in place with four (4) 3/8" Bin Bolts and four (4) 3/8" Lock Nuts.
- E. Secure to the bin wall using four (4) 3/8" Flange Bolts and four (4) 3/8" Lock Nuts through the AS-40001 Wall Bracket. There are three (3) horizontal bolt spaces between one Stair Wall Bracket Assembly and the next.


	AS-40001
Figure 1	AS-40002
	AS-40003

PARTS USED IN STEP 1			
PART NUMBER	DESCRIPTION	QTY	
AS-40001	Wall Bracket	1	
AS-40002	Cross Brace	1	
AS-40003	Diagonal Brace	1	
3/8-16x1SFB	3/8"-16 x 1" Bin Bolt	12	
3/8-16SFN	3/8"-16 Whiz Lock Nut	12	



DRAWN Marcus Wilmsmeyer 4/3/2018	Greene Galvanized Stairs	
CHECKED	East Lynn, IL 217.375.4244	
QA	www.greenebinstairs.com	
MEG	TITLE	
APPROVED	44" A-Series Sidewall Stairs Assembly	
APPROVED	Instructions	
	SIZE   DWG NO   REV	
	A AWT4400 Instructions	
	SCALE 1/17 SHEET 4 OF 11	

- A. To build the upper wall bracket (AWT4402), place the cross brace perpendicular to the wall bracket, lining up with the top set of four holes, as shown in Figure 3.
- B. Secure in place with four (4) 3/8" Flange Bolts and four (4) 3/8" Lock Nuts.
- C. Place the diagonal brace on the wall bracket and cross brace.
- D. Secure in place with four (4) 3/8" Flange Bolts and four (4) 3/8" Lock Nuts.
- E. Secure to the bin wall using four (4) 3/8" Bin Bolts and four (4) 3/8" Lock Nuts through the AS-40001 Wall Bracket. There are three (3) horizontal bolt spaces between one Stair Wall Bracket Assembly and the next.




PA	RTS USED IN STEP 2	
PART NUMBER	DESCRIPTION	QTY
AS-40001	Wall Bracket	1
AS-40002	Cross Bar	1
ES-8011	Knee Brace	1
3/8-16x1SFB	3/8"-16 x 1" Bin Bolt	12
3/8-16SFN	3/8"-16 Whiz Lock Nut	12

DRAWN Marcus Wilmsmeyer	4/3/2018			Gre	ene Galvaniz	ed Stairs	
CHECKED	, -, -			East	Lynn, IL 217	.375.4244	
QA				WW	w.greenebins	tairs.com	
1		TITLE					
MFG		44"	Δ-Ser	ies '	Sidewall S	tairs Assembl	v
APPROVED		44" A-Series Sidewall Stairs Assembly Instructions					
		Inst	ructio	ns			
		SIZE			DWG NO		REV
		Α			AWT4400	Instructions	
		SCALE	1/14			SHEET <b>5</b> OF <b>11</b>	

Inside Siderail AS-40007 will have a dot-matrix "I" denoting "inside", while Outside Siderail AS-40008 will have a dot-matrix "O", denoting "outside". Also, the outside siderail will have two slots and a hole at each end, while the inside siderail will have just the two slots.

- A. Attach the three (3) AS00030 stair treads to inside siderail AS-40007, using six (6) 3/8" Flange Bolts and six (6) 3/8" Lock Nuts. The bolt heads should be facing outwards from the assembly.
- B. Attach the other end of the three (3) AS00030 stair treads to outside siderail AS-40008, using six (6) 3/8" Flange Bolts and six (6) 3/8" Lock Nuts. The bolt heads should be facing outwards from the assembly.
- C. Tighten the nuts attached to the center stair tread. Leave the other two stair treads loose for final adjustment on the bin. Tighten after Step 6.
- D. Repeat A through C for the second set of three stairs.



PARTS USED IN STEP 3				
PART NUMBER	DESCRIPTION	QTY		
AS-40007	Inside Siderail	2		
AS-40008	Outside Siderail	2		
AS00030	30" x 11" Step Assembly	6		
3/8-16x1SFB	3/8"-16 x 1" Flange Bolt	24		
3/8-16SFN	3/8"-16 Whiz Lock Nut	24		

Greene Galvanized Stairs
East Lynn, IL 217.375.4244
www.greenebinstairs.com
TITLE
44" A-Series Sidewall Stairs Assembly

AWT4400 Instructions


SHEET 6 OF 11


Instructions


1/13

A. Place two (2) AS-40005 inside posts on the two wall brackets installed in Steps 1 and 2. Secure in place using two (2) 3/8" Flange Bolts and two (2) 3/8" Lock Nuts on each post. See Detail C for the hole location.

B. Install the first stair set onto the first of the two posts. Refer to Detail D for the location of the bolt holes. Secure in place using two (2) 3/8" Flange Bolts and two (2) 3/8" Lock Nuts.









- A. Install the AS-40006 outside post to the first wall bracket, using two (2) 3/8" Flange Bolts and two (2) 3/8" Lock Nuts. Refer to Detail F.
- B. Attach the outside post to the first stair section, using two (2) 3/8" Flange Bolts and two (2) 3/8" Lock Nuts. Refer to Detail E.


PARTS USED IN STEP 5		
PART NUMBER	DESCRIPTION	QTY
3/8-16x1SFB	3/8"-16 x 1" Flange Bolt	4
3/8-16SFN	3/8"-16 Whiz Lock Nut	4
AS-40006	Outside Post	1






Install outside post AS-40006 to the top stair section, and secure in place using four (4) 3/8" Flange Bolts and four (4) 3/8" Lock Nuts.

PARTS USED IN STEP 7			
PART NUMBER	DESCRIPTION	QTY	
3/8-16x1SFB	3/8"-16 x 1" Flange Bolt	4	
3/8-16SFN	3/8"-16 Whiz Lock Nut	4	
AS-40006	Outside Post	1	





DRAWN Marcus Wilmsmeyer 4/3/2018	3		eene Galvanized Stairs
CHECKED		East	: Lynn, IL 217.375.4244
QA		ww	w.greenebinstairs.com
	TITLE		
MFG	44"	A-Series	Sidewall Stairs Assembly
APPROVED		ructions	Sidewall Stalls / Isselfibly
	SIZE		DWG NO REV
	A		AWT4400 Instructions
	SCALE	1/15	SHEET 10 OF 11




Figure 9

PARTS USED IN STEP 8			
PART NUMBER	DESCRIPTION	QTY	
HRC1500	1.5" Handrail Clamp	6	
5/16-18x3/4FB	5/16"-18 x 13/4" Flange Bolt	6	
5/16-18SFN	5/16"-18 Whiz Lock Nut	6	
TR1504810	1.5" Swaged Handrail/Guardrail	3	
TR1004810	1.0" Swaged Indermediate Rail	2	
Floor Screw	Self-tapping screw	10	

- A. Using a Tube Roller Former, curve all rails to fit the diameter of the bin. The 1" handrails have small holes that should face towards the stairs when installed on the bin, which are screwed into when installing rails on other stair sections.
- B. The swaged ends on all rails should face up the stairs while the larger, unswaged end should point down the stair run.
- C. Using three (3) 1.5" handrail clamps, line up the 1.5" handrails with the bottom post, as shown in Detail K. Secure each handrail clamp to the post with a 5/16" Flange Bolt and 5/16" Lock Nut, and secure the handrail to the clamp with a self-tapping screw.
- D. Using the next three (3) 1.5" handrail clamps, fix the 1.5" handrails to the next post. Secure each handrail clamp to the post with a 5/16" Flange Bolt and 5/16" Lock Nut, and secure the handrail to the clamp with a self-tapping screw.
- E. Lining up the small hole on the 1" intermediate handrail, secure to the lower post using a self-tapping screw, as shown in Detail L. Then use a self-tapping screw to secure the intermediate 1" rail to the second post.

DRAWN Marcus Wilmsmeyer 4/3/2018	Greene Galvanized Stairs
CHECKED	East Lynn, IL 217.375.4244
OA	www.greenebinstairs.com
`	TITLE
MFG	44" A-Series Sidewall Stairs Assembly
APPROVED	Instructions
	SIZE DWG NO REV
	A AWT4400 Instructions
	SCALE 1/22 SHEET 11 OF 11