



RED LABTM
RAPID ENVIRONMENTAL DIAGNOSTICS
www.redlabllc.com

FOR LAB SERVICE OPTION ONLY

Field QED UVF SAMPLING PROTOCOL

We recommend for simplification purposes that clients collect soil samples with volumetric type “Terra-Core” samplers.

- 1) Add **10 grams** of soil to the prepared (20 mL methanol) VOA vial.
- 2) Shake vigorously for 1 minute
- 3) Fill out vial label in sharpie marker
- 4) Ensure that the cap threads are clear of debris as well as the glass threads on the VOA vial to achieve a strong seal.
- 5) Tightly close the VOA cap and place sample in bubble wrap sleeve.
- 6) Return the bubble wrapped vials to resealable bag.
- 7) Pack in cooler with ice, ensure that samples are sealed off from water and standing upright & ensure when ice melt they will still be standing.
- 8) Complete Chain of Custody Form and seal in Ziploc bag.
- 9) Ship to RED Lab, overnight priority shipping. If weekend shipping, ensure no signature is required and use priority Saturday shipping.

Week Day Shipping:

5598 Marvin Moss Lane
MARBIONC Bldg., Suite #2003
Wilmington, NC 28409

Weekend Shipping:

RED Lab, LLC
1609 Ebb Drive
Wilmington, NC 28409

For Bottle orders or other related questions please contact:

Hannah King
hking@redlabllc.com
(910)-508-6270