



## - CARPET HYGIENE GUIDELINE -

# PROTOCOL FOR BIO-REVEAL SAMPLING OF CARPET MATERIAL - GENERAL

---

### Statement of Use

The Bio-reveal® Ultrasnap ATP swabs and the Bio-reveal® Systemsure Plus luminometer will be used to determine the level of surface contamination for viable biological matter, such as bacteria, fungi, somatic cells, biofilms, etc. that may be present in carpet materials potentially contaminated due to water loss impaction (Category 1, 2 or 3 water), condensation formation, or poor cleaning hygiene practices. The use of the Bio-reveal® testing system will allow carpet cleaners, facility maintenance staff, restoration professionals, restoration contractors and the Indoor Environmental Professional (IEP) the real-time ability to quantify the relative level of bio-contamination associated with carpet materials used within indoor environments. Additionally, the Bio-reveal® testing system can provide quality assurance to the cleaning of carpeting or restoration process as well as post restoration verification testing for carpet decontamination or cleaning.

The Bio-reveal® bio-contamination detection system is designed to evaluate the level of surface cleanliness and sanitized hygiene within the indoor environment. This system will not detect specific strains of bacterial, viral or other micro-organisms, rather will measure and document the total surface hygiene conditions that may harbor these types of organisms as a result of dirty, unhygienic or where direct impaction of Category 1, 2 or 3 water contamination may have occurred.

***This carpet testing guideline was developed by BEM Corp. with the cooperation of and field tested use by NASA at the NASA Glenn Research Center in Ohio.***

# Methodology – Surface Sampling

## **Steps**

- 1) Identify the target surface to sample for determining the level of biocontamination present:
  - a. Carpeting materials (general, non-specific)
- 2) Use aseptic techniques for all sample collection. Remove the plastic cover or tube from the Bio-reveal® Ultrasnap ATP swab. This will expose the collection end or swab bud, which is pre-moistened to assist in sample collection. Ensure to NOT directly touch the swab bud or swab shaft with your fingers or hand or it will become contaminated.
- 3) Thoroughly swab the desired sample surface over a 2” X 2” sampling area (4 inches square) using approximately 10 strokes vertical and 10 strokes horizontal over the sample area while rotating the swab over the surface. Allow the swab bud to “clean” the sampled surface in order to accurately reflect the sampled surface contamination potential.
- 4) After swabbing place the plastic tube back over the swab bud and insert the open end back into the collar of the entire device.
- 5) Grasp the bulb end of the sampling device and the small plastic stem inside the bulb. Then break the snap valve by bending this plastic stem forward and backward until the stem breaks off. Hold the device upright during this step.
- 6) Squeeze the bulb twice to expel the reagent in the bulk down into the collection tube covering the swab bud tip.
- 7) Gently shake the device to thoroughly mix the liquid contents in the base of the device for approximately 5 seconds. This ensures the swab bud is properly washed or bathed in the reagent solution.
- 8) Insert the entire sampling device into top of the Bio-reveal® Systemsure Plus luminometer. Be sure to insert the device completely into the open port hole before closing the lid of the luminometer. **The sample device should be inserted into the luminometer and read within 60 seconds after breaking the valve stem and activating the reagent as outlined in Step 5), for the most accurate results.**
- 9) Close the lid of the Bio-reveal® luminometer.
- 10) Press the “OK” button to read the sample results. This process will take 15 seconds from the time you press the “OK” button. Be sure to hold the instrument up and down (vertical position) to obtain the best results.

# Interpretation of Bio-reveal Sampling Results

## **BIO-REVEAL INTERPRETATION FOR CARPET TESTING**

**Guideline for Surface Sampling of Carpet Building Materials  
Includes Initial Assessments, Cleaning & Post Restoration Verification Testing  
of Carpet Building Materials**  
*(Surface samples are collected using the Bio-reveal Ultrasnap swab from indoor  
environmental carpet building materials)*

<b>Sampled Surface Condition (Biological Contamination)</b>	<b>Bio-reveal Surface Sampling Result (RLU)*</b>	<b>Interpretation Result</b>
Relatively Clean or Uncompromised Carpet Materials	$\leq 100$	PASS (ACCEPTABLE)
Moderately Soiled or Potentially Contaminated Carpet Materials	$\geq 101$ and $< 300$	CAUTION (PASSING BUT DIRTY)
Heavily Soiled or Likely Compromised Carpet Materials	$\geq 300$	FAIL (NOT ACCEPTABLE)

\* RLU – Relative light unit or unit of measure for bioluminescent measurements

***This carpet testing guideline was developed by BEM Corp. with the cooperation of  
and field tested use by NASA at the NASA Glenn Research Center in Ohio.***

## Considerations when using the Bio-reveal sampling system

- a. Avoid collecting large amounts of sample debris on the swab bud. Too much sampled material may reduce signal strength of test and provide inaccurate readings or false negatives.
- b. Damaged or accidental activations of the sampling swab device should not be used and should be disposed of.
- c. Disposal of the sampling swab device can be in general waste. No special precautions are required for disposal.
- d. Hold the Bio-reveal® Systemsure II upright during Step 10).
- e. Hold the Bio-reveal® Ultrasnap ATP swab device upright when activating in Step 5).
- f. The Bio-reveal® Ultrasnap ATP swabs will tolerate room temperature storage for up to two months but all unused sampling devices should be stored in the refrigerator, where they will remain viable for up to 12 months.

For Technical Questions or Customer Service, please contact Slade Smith at:

Phone number: 866-989-5567, ext 2.

Cell number: 320-309-5448

Or

email at [info@bio-reveal.com](mailto:info@bio-reveal.com)

Bio-reveal is a registered trademark of Industrial Hygiene Consulting, Corporation,

Tel: 866-989-5567, Fax: 651-286-2665

[www.bio-reveal.com](http://www.bio-reveal.com)

## ALTERNATIVE INTERPRETATION GUIDELINE SETTINGS

### Recommended Threshold Setting Procedure

- Step 1) Identify the sample points or critical control points.
- Step 2) Clean the sample point surfaces thoroughly. This procedure may be repeated 2 or more times to achieve the best possible cleanliness.
- Step 3) Conduct ATP sampling at each location identified and cleaned, using 10 test replicates.
- Step 4) Calculate the average RLU. This will be considered the PASS level.
- Step 5) FAIL limits are determined by multiplying the PASS level by a factor of 2.
- Step 6) Caution is the region between the PASS and FAIL calculated limits.
- Step 7) Monitor results and assess the trends. Recalculation of the PASS and FAIL limits may be warranted to optimize the results and improve the quality standards.

### Alternative Threshold Setting Procedure

- Step 1) Identify the sample points or critical control points.
- Step 2) Clean the sample point surfaces thoroughly. This procedure may be repeated 2 or more times to achieve the best possible cleanliness.
- Step 3) Conduct ATP sampling at each location identified and cleaned several times and over several days, using a minimum of 50 test replicates.
- Step 4) Calculate the average and standard deviation for the documented RLU.
- Step 5) Set limits as follows:
  - Pass        $\leq$  Mean RLU
  - Caution    $\geq$  Mean RLU < Mean + 3 standard deviations
  - Fail        $\geq$  Mean RLU + 3 standard deviations