

Napco Gemini Security System

User Guide - DK1 Keypad (Stay/Away)

Cheat Sheet Version - Please refer to factory manual for further assistance.

Change/Add User Code

Only your main keypad by the Garage Door can be used to change the code. This code should be changed to your own personal user code. Please choose a code using 3-6 digits. Do not use 1-2 as a part of your code ex: 123, 1256.

Step 1: Enter **User Code** Press **Menu**.

Step 2: Press **Menu** (several times) until *Activate Program* is displayed ,
Press **Enter** *Enter User Code* should be on the display.

Step 3: U01 stands for User # 1. Up to six user codes can be entered. Press **Menu** to move the cursor. Entering U02 would allow for a second code, U03 a third etc.. Program directly over any existing codes you no longer need. Enter your user number (U01) and then new personal code (4-6 digits).

Step 4: Press **Enter** button to save new code.

Step 5: Press **Reset** to exit program mode.

To erase a user code enter digits of user code followed by menu menu. Then press * 0 to erase each digit of user code.

Ex: 02 Menu Menu * 0 * 0 * 0 * 0

Please note: The U01 User Code will be considered the main alarm code. The new code will replace 159 in step #1. Code changes can only be made from the main keypad using the U01 main code in accessing programming.

Changing Date/Time

Step 1: Enter **User Code**

Step2: Press **Menu** several times until *Activate Program* is displayed.

Step 3: Press **Stay (yes)**

Step 4: Press **Away (no)** Enter Time should be displayed.

Step 5: Enter time/date ex: 07-29-03, 06:30 . Any number will change AM/PM if needed.

The menu button can be used as a curser.

Step 6: Press **Enter** to save.

Step 7: Reset

To Arm/Disarm the System

Keypad must read *System Ready*

Leaving the Home

To Arm: Press and hold the AWAY Button. (This will activate motion detectors)

Keypad will countdown from 60 seconds until system is completely armed.

Leave the Premises.

To Disarm: Enter **User Code**, press **Enter** Button.

If code is entered too quickly the keypad may not accept it. Wait two seconds then re-enter code.

Staying at Home

To Arm: Press and hold the STAY button. (System will bypass interior motions)

Keypad will countdown from 60 seconds.

To Disarm: Enter User Code, press Enter

Instant Protection

This deletes the entry delay time on doors.

This feature will give you time to leave, but no re-entry time.

Press and hold **STAY** for 2 seconds after system has been armed in Stay Mode.

A red light will flicker rapidly to indicate instant protection.

Bypassing

Press the **Bypass** key followed by the **zone's two digit number** (04, 15) . The bypass icon will be displayed to indicate a zone has been bypassed.

To clear a bypassed zone arm and then disarm the system.

To Silence an Alarm Violation

Enter **User Code**, press **Enter**. The violated zone will be displayed. Press **Reset** button to clear.

Fire Alarm/Smoke Detectors

Not all alarms have smoke detectors tied into the security system. If your smoke detectors have a 9 volt battery that needs to be changed, they are not a part of the security system.

Smoke Detectors do need to be cleaned at least once a year. This can be done with a vacuum or a can of spray air.

Fire Alarm will be displayed on Keypad and main sirens should be sounding. If not the smoke detectors were installed by the electrician.

To Silence Fire Alarm:

Press **RESET** to silence keypad

Enter **User code**, press **Enter**

Press **Reset** to clear Fire Trouble

Please Note: If you are connected to a monitoring service the fire department will be dispatched. The monitoring company does not call to verify fire alarm signals.

Resetting System Trouble

When *System Trouble* is displayed on the keypad press **Reset** to silence sounder & reset system.

To Set Alarm off Immediately with use of Keypad.

Press the following Simultaneously

F and * Direct Fire **P and *** Direct Police **A and *** Direct Police

Silent Alarm : **1 -2 + code + off** Disarms System and sends silent signal to monitoring station.

Please Note: These features call the police only when connected to a central station. A monthly fee is required for monitoring services.

Door Chime

This is a 2 second chime from each keypad whenever a door or window is opened.

Step 1: Press **MENU** until *Activate (Deactivate) Chime* is displayed.

Step 2 : Press “yes” **STAY** (This switches the chime on and off)

Siren/Battery Check

Activates the sirens for 2 seconds. System should be checked monthly. Sirens will sound for 2 seconds and quit.

Step 1: Press **Menu** until *Activate Bell Test* in on display.

Step 2: Press “yes” **STAY**.

If alarm does not sound the back up battery may need to be replaced. It is recommended that the battery should be replaced every 3-5 years. See next paragraph.

Locating Main Alarm Panel

It is very important to find the control panel and know how to disable the alarm in case of emergency (ex: keypad failure or power surge). The control panel is located in a white metal box hanging on a wall in a basement or closet area. You will need a screwdriver to open the box. Inside the box is the back up battery, remove the plastic terminals from the battery. Next locate the transformer (a small 2” black or tan plug) plugged into an electrical outlet near the panel box. It may be screwed into the electrical outlet. Once both the transformer and battery are unplugged the security system will be shut down. The keypads should have no lights. Until the power is restored the system will remain deactivated. No information will be lost in the memory except for the date and time.

Using a Central Station to contact the Police

This alarm system has a digital communicator built in to the control panel box that will allow you to connect with a monitoring company. Vacuflo does offer this service with a through Affiliated Central. There is no hook up fees and the monthly rate is \$25. 00. Billing is done in 3, 6 or 12 month cycles. Annual billed customers receive a \$25 discount. A long term contract is not required to be signed. Please contact the office for more information. Fayette County residents do need to apply for and receive the False Alarm Reduction Permit before monitoring service can be activated.

Keypad Messages

E01- 00 AC POWER FAILURE: General Power Outage. Check Transformer.

E02-00 LOW BATTERY: Weak Battery, if not recharged within 24 hours replace. Batteries have a 3-5 year life span. Located in Main Panel Box.

E03-00 COMM FAIL: Failure to communicate with Central Station. Recent phone work or DSL service can interrupt communication.

E04-NN: Wireless systems. A transmitter has not communicated with the main panel . NN denotes zone number.

E05-NN Wireless systems. A transmitter's battery is low. Replace Battery. NN denotes zone number.

For Service or Monitoring Issues Please Contact:

CIVA INC.
Vacuflo of Kentucky
349 Southland Drive
Lexington, KY
859-276-0404

Business Hours: Monday - Friday 8:30 to 4:00