



McGAUGHY'S
S U S P E N S I O N P A R T S

559-226-8196
4603 E. VINE AVE.
FRESNO, CA 93725

2019+ DODGE RAM 2500, 4" LIFT KIT
PART# 54406 (COIL SPRING REAR)

*****READ ENTIRE INSTRUCTIONS BEFORE STARTING ANYTHING*****


- Before moving forward with the installation, please lay out all parts to ensure that nothing is missing. If there are any missing parts, please contact McGaughy's Suspension immediately at 559-226-8196.
- If any parts are ground on or modified in any way, then no returns will be accepted. And any warranty on all parts will be void.
- No welding is required to install any part of this kit. DO NOT weld any components.
- Oversized tires and heavier wheels can cause premature wear on all factory suspension components. You may need to install new components sooner than factory recommendations based on the wheels and tires you choose.

1. FRONT LIFT COILS
2. REAR COIL SPACERS
3. RADIUS ARMS
4. FRONT TRACK BAR BRACKET
5. REAR TRACK BAR BRACKET
6. FRONT BUMP STOP DROP BRACKETS
7. REAR SHOCK EXTENDERS
8. RADIUS ARM DROP SPACERS
9. REAR BUMP STOP DROP BRACKETS
10. FRONT SWAY BAR DROP BRACKETS
11. REAR SWAY BAR LINK ENDS
12. FRONT SHOCKS
13. HARDWARE PACKS

www.mcgoughys.com


FRONT INSTRUCTIONS

With the vehicle turned off and parking brake set, secure the rear of the vehicle with wheel chocks. Use a jack to lift the front of the vehicle and place jack stands under the frame on each side.



1. Disconnect the brake lines from the front axle on both sides. There will be four bolts total. Use a 13mm socket. (pic 1-2)

2. Disconnect the sway bar link on both sides. Use a 18mm socket. (pic 3)



3. Loosen the nut on pitman arm and remove drag link. Use a 21mm socket. (pic 4)


4. Remove the track bar bolt from track bar. Use a 27mm socket. (pic 5)

5. Support the front axle. Raise the axle slightly to take the weight of the shocks. Remove the lower shock bolt on both sides. Use a 21mm socket. (pic 6)



6. Slowly lower the front axle. Be sure to keep brake lines, abs lines, and the electronic 4wd cylinder wire (on passenger side) clear of any obstructions. Do not over extend the drive line. It can break or bend if dropped too far. Be careful not to let the front coils fall as you lower the axle. (pic 7)

7. Remove the factory coils. Be sure to save the coil isolators to reuse on the new lift coils. (pic 8-9)



8. Unbolt the factory front track bar mount. Use a 21mm socket. (pic 10-11)


9. Disconnect the factory radius arms using a 27mm socket on the front upper bolt and a 24mm socket on the front lower bolt. Use a 27mm socket on the frame bolts and remove the factory radius arm from vehicle. (pic 12)



10. Install new radius arms in the factory location using the factory hardware. (pic 13)


11. Be sure to set the cam bolts the same on both sides when installing. Torque the axle bolts to factory specs. (pic 14-15)

12. On the frame side, leave those bolts snug only. Only tighten them once vehicle is on the ground. Be sure to torque them to factory specs when on the ground.



13. Install new front track bar bracket. Use the factory hardware, except for the inside nuts. Two new nuts are supplied. Torque to factory specs. (pic 16-17)

14. Use a cut off wheel to remove the factory bump stop mounts. The factory mounts will be reused, so do not destroy. Use the provided tap on the frame in the existing holes. Now install the factory bump stop mount on to the new drop down brackets using the supplied allen hardware. Then install the drop down bracket on to the frame using the provided hardware in the factory. (pic 18-19)




15. Install new front sway bar drop brackets using the provided 3/8" x 1" bolts. Install the factory sway bar mounts onto the new drop brackets using the factory hardware. (pic 20-21)



16. Install new lift coils. Be sure to use the factory coil isolators on the top and bottom of the new lift coils. The tighter windings on the coil will go towards the top on the frame. (pic 22)

17. Install the new front shocks into the factory location using the factory hardware. (pi 23)



18. Now tighten the radius arm bolts. Go over the other bolts to make sure they are tight as well. (pic 24)

19. Install the factory track bar into the new track bar bracket using the factory hardware. Torque to factory specs. (pic 25)


20. Install the factory drag link using the factory hardware. Torque to factory specs.

21. Install the sway bar end link using the factory hardware. (pic 26)


22. The front is now finished. Go over all the bolts to make sure everything is tight and torqued to proper specs.

REAR INSTRUCTIONS

With the vehicle turned off and parking brake set, secure the front of the vehicle with wheel chocks. Use a jack to lift the rear of the vehicle and place jack stands under the frame on each side. Properly support the rear end housing.






1. Remove the factory sway bar end links. (pic 1)
2. Remove the factory lower shock bolts. (pic 2)
3. Slowly lower the rear end housing. Be sure all brake lines and wires are clear of any obstructions.
4. Remove the factory coil springs and rubber isolators. (pic 3)



5. Install new rear coil spacers. There is no difference between the two sides, but the spacer will only mount one way. The longer tab will be towards the front of the truck. Use the provided 3/8" x 1-1/4" bolts. (pic 4-6)



6. Install the factory rear coils and rubber isolators. (pic 7)
7. Underneath the factory track bar mount, there is a small hole that needs to be drilled out to 1/2". (pic 8-9)



8. Install rear track bar bracket. Use the factory hardware on the lower hole. Use the provided 9/16" hardware to bolt the factory track bar into the new bracket. The rear 3/8" 1-1/4" bolt that is holding the new coil bucket to the rear housing will be used to bolt the new track bar bracket in place. Use the provided 1/2" x 1-1/2" bolt and install it into the hole you drilled underneath the factory track bar mount. This bolt will go through the factory mount and new track bar bracket. (pic 10-11)

9. Now with all the bolts in place, start with the original lower bolt and torque to factory specs. Next tighten the 3/8" bolt goes through the bracket and through the rear end housing and through the new coil spacer. Torque to 35 lbs. Last, tighten the 1/2" bolt that goes through the bottom of the factory mount and through the new track bar bracket. Torque to 70 lbs.

10. Now install the factory track bar using the provided 9/16" x 4" bolt. Torque to 85 lbs. (pic 12)



11. Install rear bump stop drop brackets using the provided 3/8" x 1-1/4" bolts. (pic 13-14)

12. Install rear shock extenders using the provided 9/16" x 3" hardware. (pic 15)



13. Install new rear sway bar link ends. Upper mount may need to be drilled out to 1/2". Use the provided 1/2" x 2-3/4" hardware. (pic 16-18)

14. Rear is now finished. Be sure to go through all bolts to make sure they are tightened to proper specs.