

ENTERING CASH QUANTITIES INTO TRITON SOFTWARE

1. Hold down the (1) and BLANK key buttons on the keypad
2. Login with your pass code and hit ENTER
3. Choose number (1) on the keypad
4. Choose Number (6) on the keypad
5. Choose ENTER
6. Choose ENTER again and ENTER again
7. Enter quantity of bills and then hit ENTER
8. Here you can press (3) to print out receipt and then choose ENTER
9. Choose CANCEL several times to return to main screen