



CAUTION

WHEEL TORQUE REQUIREMENTS

Wheel nuts or bolts must be tightened and maintained at the proper torque levels to prevent loose wheels, broken studs, and possible dangerous separation of wheels from your axles, which can lead to an accident, personal injuries or death. Re-torque after the first 10 miles, 25 miles, and again at 50 miles. Check with wheel manufacturer for proper torque values.

1/2-20	90-120 Ft. Lbs.
--------	-----------------

9/16-18	90-120 Ft. Lbs.
---------	-----------------

5/8-18	190-210 Ft. Lbs.
--------	------------------


90° Cone Nut With Clamp Ring	
------------------------------	--

5/8-18	275-325 Ft. Lbs.
--------	------------------


Non-Swiveling Flange Nut	
--------------------------	--

5/8-18	150-175 Ft. Lbs.
--------	------------------


Swiveling Flange Nut	
----------------------	--



5 BOLT



6 BOLT



8 BOLT

