

If we are treating from the exterior only, please follow 3 - 8.

Dear Valued Customer,

Oklahoma Termite Specialist, Inc. 14843 Bristol Park Blvd. Edmond, OK 73013

Office: (405) 330-5030 Fax: (405) 330-5031

Treatment Preparation Information Sheet

We have property address	scheduled for a treatment
on at	
In order to do the treatment properly, there are a few things	we ask that you do to help prepare your home.
If we are treating your home from the interior and exterior, please follow steps 1-8.	

- 1. INSIDE HOME Move all items 3 feet from *all exterior* walls (walls that face the outside) of the home If you have items that you are unable to move, such as built-ins, we can work around that. If closets are located on an exterior wall, items will need to be moved from inside these areas as well. Oklahoma Termite Service Technicians *do not* move furniture and/or items on the property.
- 2. Please prepare for a light covering of dust from the drilling. Furniture and belongings must be moved and/or covered previous to treatment otherwise we will not be able to adequately treat the area.
- 3. INSIDE GARAGE Move all items 3 feet from *all* walls in the garage (attached or detached). All garages must be treated from the *inside*.
- 4. OUTSIDE HOME Move any items that may be up against the home on the outside such as potted plants, furniture, portable storage, firewood, etc.
- 5. Have the utilities on. We will need electricity and water to operate our equipment.
- 6. Please be sure that the treatment agreement has been signed and returned to the office *before* treatment begins.
- 7. Please be aware that the drills can be very loud. Prepare for this if you plan on being home at the time of treatment.
- 8. We will not drill through tile, brick, or wood flooring. We will treat these areas from the outside. Carpet will be pulled from the wall; we will drill the concrete and replace the carpet. If we are unable to access certain areas for treatment, it will be addressed on the treatment graph. If you want an area treated that we normally would not drill, a consent form will need to be signed *before* treatment.

Paperwork for the treatment will be left at the home. We will either leave it with the person who opens the home for us or we will leave it on the kitchen counter if no one is available. Please discuss this with your Realtor, if applicable, so that you will have the paperwork needed for closing. If the home is not for sale, a copy of the graph and invoice will be left with the owner.

FYI - Weather can sometimes keep us from treating. If it is rainging, snowing, or the ground is too wet in a crawl space we may have to reschedule. We realize that this is inconvenient for you and it tends to also put us behind, but we want to do the best job we can even if that means rescheduling to ensure proper treatment.

We thank you four your business and cooperation. If you have any questions, please do not hesitate to contact our office.