




REDIBASE


CONSTRUCTION TUBE FOOTING FORM FOOTING SYSTEM




Center REDIBASE over tube




Push REDIBASE down over tube to ground.



Pull tube up through REDIBASE flaps until either 8" or 10" small side tabs, slip under tube bottom.



Snug tube down into side tab formed slots



Apply 4 - 5 passes of duct tape, from app tube bottom to 1" above flap tips

6

Place taped form in excavation. Level and align with any other forms. Shovel and tamp small amount of backfill on and around base to hold in place for backfilling.

Min. 4 1/2"

7

Backfill to grade. Maintain tube vertical level and alignment. Leave 6" - 12" tube protruding..

8

Place rebar (optional)
Fill with concrete.
*Note: under dry conditions, concrete pour can be delayed up to 48 hours.