

How to figure drawer inside width and depth.

This chart will give actual inside dimensions. It is up to you to determine accessory clearance.

Undermount:

Width: Opening less 1.688

Depth:

12" = 10.688"

14" (13.375") = 12.082"

15" = 13.688"

18" = 16.688"

21" = 19.688"



Example:

Opening = 24"

Less 1.688 = 22.312

Side Mount:

Width: Opening less 2.375

Depth:

10" = 8.438"

12" = 10.438"

14" = 12.438"

16" = 14.438"

18" = 16.438"

20" = 18.438"

22" = 20.438"



Zargen:

Width: Opening less 1.22

Depth:

14" = 12.91"

16" = 14.88"

18" = 16.45"

18.875" = 17.64"

20.25" = 19.21"

21.654" = 20.78"

