

# Phosphonate (OP) Test Kit

1 drop = 0.7 ppm as active OP / 10 mL

**TK0159-Z**  
purple caps

## KIT COMPONENTS:

AD1596-DB OP Titrant #2, 60 mL  
AD1582-100 OP Tablets, 100 pack  
PT502 Tablet Crusher  
VL-0525-V Vial, 5-25 mL

## SAFETY TIPS:



Wear  
Gloves



Use Eye  
Protection



Read  
SDS

## TESTING TIPS:



Collect  
Accurate  
Sample



Hold  
Bottles  
Vertically




Ensure  
Proper  
Lighting

**INTERFERENCES:** As little as 0.5 ppm Fluoride and 1 ppm Orthophosphate will cause interference. Even low concentrations of Iron and Sulfate will cause interference. Highly alkaline samples may resist buffering. To handle high alkalinity follow the note in Step 2.


**ATTENTION:** As necessary, calibrate this kit against a known standard made with plant / make-up water. Be sure to collect a representative sample.

**1** Rinse vial three times with sample to be tested. **Fill vial to 10 mL.**



**2** Add 1 OP Tablet (AD1582) crush and swirl to mix. A green color will develop.


For high alkalinity samples, 2-3 tablets may be necessary to properly buffer the sample.



**3** Add OP Titrant (AD1596) one drop at a time while swirling. Count the number of drops until the sample color changes from green to purple. A gray intermediate color may develop. Keep titrating to the purple endpoint.

# drops x 0.7 = ppm as OP\*

*\*For best accuracy, run a blank on the make-up water and subtract the number of drops from the final test results.*



Video Procedure

