

Hardness (Total) Test Kit

1 drop = 0.5 or 10 ppm as CaCO₃ / 25 mL

TK3012-Z
blue caps

KIT COMPONENTS:

ED2064-B	Trace Hardness Titrant, 60 mL
ED2070-B	Hardness Titrant High, 60 mL
HA7405-A	Hardness Buffer Solution, 30 mL
HA7475-H	Hardness Indicator Powder, 10g
VL-1005-V	Vial, 10-50 mL

SAFETY TIPS:



Wear
Gloves



Use Eye
Protection



Read
SDS

TESTING TIPS:



Collect
Accurate
Sample



Hold
Bottles
Vertically




Ensure
Proper
Lighting


INTERFERENCES: Metals may cause difficulty in seeing the endpoint. If metal interference is presumed, add one drop of Hardness Titrant to the sample before adding buffer or indicator. Include this drop of titrant when calculating your results. Additional Hardness Buffer may be necessary to view a clean endpoint.

ATTENTION: As necessary, calibrate this kit against a known standard made with plant / make-up water. Be sure to collect a representative sample.

- 1** Rinse vial three times with sample to be tested. **Fill vial to 25 mL.**




- 2** Add 5 drops of Hardness Buffer (HA7405) and swirl to mix.



- 3** Add 1 scoop of Hardness Indicator Powder (HA7475) and swirl to mix.


Note: The sample will turn red if hardness is present and blue if there is no hardness.



- 4** Add Hardness Titrant one drop at a time while swirling. Count the number of drops until the sample color changes from red to blue.

Trace Hardness Titrant (ED2064)
drops x 0.5 = ppm as CaCO₃

Hardness Titrant High (ED2070)
drops x 10 = ppm as CaCO₃



Video Procedure

